

















































Originale	Sostituto
 Power	 Power
 TV	 Display / Media
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 PRE-CH	 Shift + Fav / Marker / PC
 Vol+	 Vol+
 FAV.CH	 Fav / Marker / PC
 Vol-	 Vol-
 Mute	 Mute / Dimmer

Originale	Sostituto
 PR+	 CH+ / Page+
 PR-	 CH- / Page-
 Source	 AV / Input / RDS
 Info	 Info / Angle
 Menu	 Menu / Home
 Guide	 Guide / EPG / -/--
 Tools	 Setup / OPT /
 Return	 Back / Return
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 Enter	 OK
 CH List	 Smart / List
 Exit	 Exit / Cancel / Clear
 Red	 Red / Netflix / Search
 Green	 Green / APP / Repeat





Originale	Sostituto	Originale	Sostituto
 Yellow	 Yellow / YouTube / Repeat		
 Blue	 Blue / Prime Video / Random		
 TTX/MIX	 Text / Goto		
 AD	 Audio / Lang I/II		
 SUBT.	 Subtitle / EQ		

Originale	Sostituto

