







































































Originale	Sostituto	Originale	Sostituto
 Power	 Power	 Up	 Up
 i	 DISPLAY INFO	 Down	 Down
 AUDIO I/II	 SOUND DUAL	 Right	 Right
 [...]	 AD SUBT	 Left	 Left
 1	 1	 ENTER/CH LIST	 OK
 2	 2	 MUTE	 MUTE
 3	 3	 PICTURE SIZE	 ECO 3D
 4	 4	 +	 + VOL
 5	 5	 -	 VOL -
 6	 6	 + P	 + CH
 7	 7	 P -	 CH -
 8	 8	 FREEZE/[+]	 HOME SMART
 9	 9	 RETURN	 CLEAR EXIT
 0	 0	 P<->P/[≡o]/[≡*]	 FAV PRE-CH
 INPUT SELECT	 TIMER AV	 TV	 SEARCH TV/R
 GUIDE (EPG)	 GUIDE	 MEDIA	 APP MEDIA
 MENU	 TOP MENU MENU	 PLAY MODE REC LIST	 PICTURE FORMAT



