





































































Originale	Sostituto
 Mute	 Mute / Dimmer
 Power	 Power
 Timer/□□	 Sleep / Timer
 []/T-C	 Picture / Format
 Audio/Repeat	 Shift + Green / APP / REPEAT
 Audio/Repeat	 Audio / Lang I/II
 [+]/Eye/SV	 Display / Media
 →[]←/Disc Menu/SP/LP	 D.Menu / Top
 Radio/Search/000	 Shift + Red / Netflix / SEARCH
 Radio/Search/000	 TV/Radio /
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7

Originale	Sostituto
 8	 8
 9	 9
 */EPG	 Guide / EPG / -/--
 0/AV	 AV / Input / RDS
 0/AV	 0
 #/PIP	 Smart / List
 Menu	 Menu / Home
 End	 Exit / Cancel / Clear
 Text	 Text / Goto
 Info	 Info / Angle
 P+	 CH+ / Page+
 Vol-	 Vol-
 Up	 Up
 Left	 Left
 OK	 OK
 Right	 Right
 Vol+	 Vol+





































	Originale	Sostituto	Originale	Sostituto





Originale	Sostituto
 Mute	 Mute / Dimmer
 Power	 Power
 Timer/□□	 Sleep / Timer
 []/T-C	 Picture / Format
 [+] / Eye / SV	 Display / Media
 → [] ← / Disc Menu / SP / LP	 D.Menu / Top
 Radio/Search/000	 Shift + Red / Netflix /
 Radio/Search/000	 TV / Radio /
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9

Originale	Sostituto
 0 / AV	 AV / Input / RDS
 0 / AV	 0
 Menu	 Menu / Home
 End	 Exit / Cancel / Clear
 Text	 Text / Goto
 Info	 Info / Angle
 P+	 CH+ / Page+
 Up	 Up
 Left	 Left
 OK	 OK
 Right	 Right
 Down	 Down
 P-	 CH- / Page-
 Red	 Red / Netflix / Search
 Green	 Green / APP / Repeat
 Yellow	 Yellow / YouTube / Repeat
 Blue	 Blue / Prime Video / Random









































































	Originale	Sostituto	Originale	Sostituto
		<< / Tune-		
		Play / Slow		
		>> / Tune+		
		Rec / Rec Mode		
		Pause / Step / Freeze		
		Stop / Hold		











Originale	Sostituto
	 Mute / Dimmer
	 Power
	 Sleep / Timer
	 Picture / Format
	 Green / APP / Repeat
	 Audio / Lang I/II
	 Display / Media
	 D.Menu / Top
	 Red / Netflix / Search
	 TV/Radio /
	 1
	 2
	 3
	 4
	 5
	 6
	 7

Originale	Sostituto
	 8
	 9
	 0
	 AV / Input / RDS
	 Menu / Home
	 Exit / Cancel / Clear
	 Info / Angle
	 CH+ / Page+
	 Up
	 Left
	 OK
	 Right
	 Down
	 CH- / Page-
	 << / Tune-
	 Play / Slow
	 >> / Tune+





Originale		Sostituto	
	Rec		Rec / Rec Mode
	Pause		Pause / Step / Freeze
	Stop		Stop / Hold

Originale		Sostituto	

