





































Originale	Sostituto
 Power	 Power
 TV/Radio	 TV/R
 Subtitle	 Subt
 AV Mode	 3D
 Ratio	 Format
 Input	 AV
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 List	 List

Originale	Sostituto
 Q.View	 Smart
 FAV	 Pre Ch
 Guide	 Guide
 Vol+	 Vol +
 Vol-	 Vol -
 Mute	 Mute
 PR+	 Ch +
 PR-	 Ch -
 Text	 Text
 Info	 Info
 T.Opt	 Shift + Options
 Settings	 Options
 Q.Menu	 D. Menu
 Back	 Back
 Exit	 Exit
 Up	 Up
 Down	 Down



