







































































Originale		Sostituto		Originale		Sostituto	
	Power		Power		Blue / Title		Blue
	HDMI Control		Smart		1		1
	Rec		Rec		2		2
	Play		Play		3		3
	Pause		Pause		4		4
	Stop		Stop		5		5
	I<<		I<<		6		6
	<<		<<		7		7
	>>		>>		8		8
	>>I		>>I		9		9
	Screen		Format		0		0
	Lang		Dual		Text		Text
	Subtitle		Subt		Swap		Pre Ch
	PIP / World		3D		Up		Up
	Red / Zoom		Red		Right		Right
	Green / Repeat		Green		Down		Down
	Yellow / Root		Yellow		Left		Left





Originale		Sostituto	
	OK		Ok
	P/CH +		Ch +
	P/CH -		Ch -
	Mute		Mute
	Vol +		Vol +
	Vol -		Vol -
	Menu		Menu
	Source		AV
	Return		Back
	EPG		Guide
	Info		Info
	Sleep		Sleep
	FAV		Shift + Pre Ch
	Angle / Media		Media
	Search Mode		TV/R
	Display		Shift + Info
	Presets		List

Originale	Sostituto

