









































Originale	Sostituto
 Power	 Power
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 List	 List
 Recall	 Back
 Vol+	 Vol +
 Vol-	 Vol -
 Aspect	 3D

Originale	Sostituto
 Home	 Smart
 CH+	 Ch +
 CH-	 Ch -
 Menu	 Menu
 Source	 AV
 Exit	 Exit
 Display	 Info
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 Enter	 Ok
 P.Mode	 Shift + Format
 S.Mode	 Dual
 Sleep	 Sleep
 MTS	 Options
 Rec	 Rec





Originale		Sostituto	
	Guide		Guide
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	<</Index		<<
	Play		Play
	Pause/Cancel		Pause
	>>		>>
	I<</Sub.PG		I<<
	>>I/Reveal		>>I
	Stop/Mix		Stop
	TTX		Text
	CAP		Media
	Subtitle		Subt
	Tv/Radio		TV/R
	FAV		Pre Ch

Originale		Sostituto	
	Size/Mouse		Format
	Hold/Refresh		D. Menu

