







































































Originale		Sostituto		Originale		Sostituto	
	Standby		Power		Right		Right
	Display		Shift + Info		Down		Down
	Nicam / Eject		Eject		Source		AV
	Mute		Mute		Exit		Exit
	P.Mode		Shift + Format		1		1
	S.Mode		Shift + Dual		2		2
	Sleep		Sleep		3		3
	Aspect		Format		4		4
	Vol -		Vol -		5		5
	Vol +		Vol +		6		6
	CH -		Ch -		7		7
	CH +		Ch +		8		8
	LCD-Menu		Menu		9		9
	DVD-Setup		Options		0		0
	Up		Up		Recall		Back
	Left		Left		Text / Audio		Text
	Enter		Ok		Hold / A-B / Rec List		Smart



