





































Originale	Sostituto
 Power	 Power
 Open / Close	 Eject
 VCR	 Media
 DVD	 Smart
 Input	 AV
 1 / Tracking -	 1
 2	 2
 3 / Tracking +	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 P.Scan	 Pre Ch
 Clear	 Exit

Originale	Sostituto
 Menu	 Menu
 Setup	 Options
 Up / PR+	 Up
 Up / PR+	 Ch +
 Down / PR-	 Down
 Down / PR-	 Ch -
 Right	 Right
 Left	 Left
 Enter	 Ok
 Skip	 Back
 Display	 Info
 Subtitle	 Subt
 Audio	 Dual
 Edit	 Guide
 Zoom	 Shift + Eject
 Play/Pause	 Pause
 << REW	 <<



