
















Originale	Sostituto
 Power	 Power
 Standby	 +  Shift + Power
 Multi CH In	 Smart
 Audio Sel	 Media
 Sleep	 Sleep
 Mute	 Mute
 CD	 2
 MD/CD-R	 3
 TUNER	 4
 DVD	 5
 DTV/CBL	 6
 DVR	 7
 V-AUX	 8
 USB	 1
 Scene 1	 Red
 Scene 2	 Green
 Scene 3	 Yellow

Originale	Sostituto
 Scene 4	 Blue
 Level	 D. Menu
 Menu	 Menu
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 Enter	 Ok
 Return	 Back
 Display	 Info
 Volume+	 Vol +
 Volume-	 Vol -
 Prog-	 Ch -
 Prog+	 Ch +
 Enhancer	 +  Shift + 1
 Straight	 +  Shift + 3
 Sur. Decode	 +  Shift + 2



























































Originale	Sostituto
Night	+ Shift + 5
Direct ST	+ Shift + 4

Originale	Sostituto







































































Originale	Sostituto
 Power AV	 Power
 Mute	 Mute
 Band	 Smart
 Menu	 Menu
 Preset+	 Up
 Preset-	 Down
 A/B/C/D/E+	 Right
 A/B/C/D/E-	 Left
 Enter	 Ok
 Return	 Back
 Display	 Info
 Volume+	 Vol +
 Volume-	 Vol -
 Freq / Text	 Text
 EON	 Media
 PTY SEEK Mode	 Ch -
 PTY SEEK Start	 Ch +

Originale	Sostituto
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 ENT	 Pre Ch







































































Originale		Sostituto		Originale		Sostituto	
	Power AV		Power		<<		<<
	Mute		Mute		>>		>>
	Title		Smart		<<		<<
	Menu		Menu		>>		>>
	Up		Up		1		1
	Left		Left		2		2
	Enter		Ok		3		3
	Right		Right		4		4
	Down		Down		5		5
	Return		Back		6		6
	Display		Info		7		7
	Volume+		Vol +		8		8
	Volume-		Vol -		9		9
	Rec		Rec		0		0
	Stop		Stop		+10		Guide
	Pause		Pause		ENT		Pre Ch
	Play		Play				





Originale	Sostituto	Originale	Sostituto
 Power AV	 Power	 <<	 <<
 Mute	 Mute	 >>	 >>
 Title	 Smart	 <<	 <<
 Menu	 Menu	 >>	 >>
 Up	 Up	 1	 1
 Left	 Left	 2	 2
 Enter	 Ok	 3	 3
 Right	 Right	 4	 4
 Down	 Down	 5	 5
 Return	 Back	 6	 6
 Display	 Info	 7	 7
 Volume+	 Vol +	 8	 8
 Volume-	 Vol -	 9	 9
 Rec	 Rec	 0	 0
 Stop	 Stop	 +10	 Guide
 Pause	 Pause	 ENT	 Pre Ch
 Play	 Play		

