



Originale	Sostituto
 Power	 Power
 Mute	 Mute / Dimmer
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 TV / Radio	 TV/Radio /
 0	 0
 Recall / Mouse	 Back / Return
 P.Mode	 Picture / Format
 S.Mode	 Sound / Title
 Nicam / A2	 Audio / Lang I/II

Originale	Sostituto
 Sleep	 Sleep / Timer
 Source	 AV / Input / RDS
 CH +	 CH+ / Page+
 Vol +	 Vol+
 Info	 Info / Angle
 CH -	 CH- / Page-
 Vol -	 Vol-
 Home	 Shift + Menu /
 FAV	 Fav / Marker / PC
 Settings	 Setup / OPT /
 ASP	 Smart / List
 Up	 Up
 Left	 Left
 OK	 OK
 Right	 Right
 Menu	 Menu / Home
 Down	 Down



