







































































Originale		Sostituto		Originale		Sostituto	
	Setup		Setup / OPT /		Pause		Pause / Step / Freeze
	Power		Power		Play		Play / Slow
	DVD Menu		D.Menu / Top		OK		OK
	Source		AV / Input / RDS		Radio(Tv)		TV/Radio /
	LCD On/Off		Shift + Power		List		Smart / List
	Exit		Exit / Cancel / Clear		FAV		Fav / Marker / PC
	Stop		Stop / Hold		Info		Info / Angle
	I<<		I<< / Preset-		EPG		Guide / EPG / -/-
	>>I		>>I / Preset+		Subtitle		Subtitle / EQ
	CH+		CH+ / Page+		Audio		Audio / Lang I/II
	Up		Up		Teletext		Text / Goto
	CH-		CH- / Page-		Mute		Mute / Dimmer
	Down		Down		Vol-		Vol-
	Left		Left		Vol+		Vol+
	<<		<< / Tune-		1		1
	>>		>> / Tune+		2		2
	Right		Right		3		3



