





































Originale	Sostituto
 Power	 Power
 Function	 TV/Radio /
 Eject	 Eject / Surround
 Sleep	 Sleep / Timer
 1 / RDS Display	 1
 2	 2
 3 / TA	 3
 4 / PTY -	 4
 5 / PTY Search	 5
 6 / PTY +	 6
 7	 7
 8	 8
 9	 9
 Full Screen	 Zoom / Size
 0	 0
 Repeat	 Shift + Green / APP /
 I<<	 I<< / Preset-







Originale	Sostituto
 >>I	 >>I / Preset+
 <<	 << / Tune-
 >>	 >> / Tune+
 Stop	 Stop / Hold
 Play	 Play / Slow
 Pause	 Pause / Step / Freeze
 Vol +	 Vol+
 Mute	 Mute / Dimmer
 Tuning / CH +	 CH+ / Page+
 Vol -	 Vol-
 V.Sound	 Sound / Title
 Tuning / CH -	 CH- / Page-
 Disc Menu	 D.Menu / Top
 Menu	 Menu / Home
 Title Menu /	 Picture / Format
 Title Menu /	 Shift + Menu /
 Tools	 Setup / OPT /



Tools



Originale	Sostituto
 Power	 Power
 TV Source	 AV / Input / RDS
 Sleep	 Sleep / Timer
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 I<<	 I<< / Preset-
 >>I	 >>I / Preset+
 <<	 << / Tune-
 >>	 >> / Tune+

Originale	Sostituto
 Stop	 Stop / Hold
 Play	 Play / Slow
 Pause	 Pause / Step / Freeze
 Vol+	 Vol+
 Mute	 Mute / Dimmer
 CH+	 CH+ / Page+
 Vol-	 Vol-
 CH-	 CH- / Page-
 Menu	 Menu / Home
 Tools	 Setup / OPT /
 Up	 Up
 Info	 Info / Angle
 Left	 Left
 Enter	 OK
 Right	 Right
 Return	 Back / Return
 Down	 Down



