












































































Originale	Sostituto	Originale	Sostituto
 Power	 Power	 Return	 Back / Return
 Open/Close	 Eject / Surround	 Setup	 Setup / OPT /
 1	 1	 Up	 Up
 2	 2	 Title	 Sound / Title
 3	 3	 Left	 Left
 Tv-Mode	 Picture / Format	 Enter	 OK
 4	 4	 Right	 Right
 5	 5	 Menu	 Menu / Home
 6	 6	 Down	 Down
 7	 7	 Audio	 Audio / Lang I/II
 8	 8	 N/P	 Smart / List
 9	 9	 Zoom	 Zoom / Size
 10/0	 0	 Step	 Shift + Pause / Step /
 10+	 Guide / EPG / -/-	 Vol+	 Vol+
 Dvd/Usb	 AV / Input / RDS	 Vol-	 Vol-
 Display	 Display / Media	 I<<	 I<< / Preset-
 PBC	 Fav / Marker / PC	 >>I	 >>I / Preset+

Originale	Sostituto	Originale	Sostituto
 Power	 Power	 Return	 Back / Return
 Open/Close	 Eject / Surround	 Setup	 Setup / OPT /
 1	 1	 Up	 Up
 2	 2	 Title	 Sound / Title
 3	 3	 Left	 Left
 Tv-Mode	 Picture / Format	 Enter	 OK
 4	 4	 Right	 Right
 5	 5	 Menu	 Menu / Home
 6	 6	 Down	 Down
 7	 7	 Audio	 Audio / Lang I/II
 8	 8	 N/P	 Smart / List
 9	 9	 Zoom	 Zoom / Size
 10/0	 0	 Step	 Shift + Pause / Step /
 10+	 Guide / EPG / -/-	 Vol+	 Vol+
 Dvd/Usb	 AV / Input / RDS	 Vol-	 Vol-
 Display	 Display / Media	 I<<	 I<< / Preset-
 PBC	 Fav / Marker / PC	 >>I	 >>I / Preset+



