



















































































| Originale | Sostituto |
|--|--|
|  Power |  Power |
|  Mute |  Mute / Dimmer |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |
|  9 |  9 |
|  Still |  Shift + Pause / Step / |
|  0 |  0 |
|  Recall |  Back / Return |
|  P.Mode |  Picture / Format |
|  S.Mode |  Sound / Title |
|  Audio |  Audio / Lang I/II |

| Originale | Sostituto |
|---|--|
|  Menu |  Menu / Home |
|  Source |  AV / Input / RDS |
|  UP |  Up |
|  Left |  Left |
|  OK / Enter |  OK |
|  Right |  Right |
|  Exit |  Exit / Cancel / Clear |
|  Down |  Down |
|  Info |  Info / Angle |
|  Media |  Display / Media |
|  CH+ |  CH+ / Page+ |
|  Auto / PVR List |  Smart / List |
|  Vol+ |  Vol+ |
|  CH- |  CH- / Page- |
|  Sleep |  Sleep / Timer |
|  Vol- |  Vol- |
|  Red |  Red / Netflix / Search |





| Originale | Sostituto |
|---|---|
|  Green |  Green / APP / Repeat |
|  Yellow |  Yellow / YouTube / Repeat |
|  Blue |  Blue / Prime Video / Random |
|  << / Text |  Text / Goto |
|  << / Text |  << / Tune- |
|  >> / Hold |  Shift + Stop / |
|  >> / Hold |  >> / Tune+ |
|  << / Mix |  << / Preset- |
|  >> / Reveal |  >> / Preset+ |
|  Play/Pause / Index |  Play / Slow |
|  Play/Pause / Index |  Pause / Step / Freeze |
|  Stop / Size |  Zoom / Size |
|  Stop / Size |  Stop / Hold |
|  Fav |  Fav / Marker / PC |
|  Scale |  Setup / OPT / |
|  EPG |  Guide / EPG / -/-- |
|  DTV / Radio |  TV/Radio / |

| Originale | Sostituto |
|--|--|
|  Rec |  Rec / Rec Mode |
|  Subtitle |  Subtitle / EQ |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

