


























































































Originale	Sostituto	Originale	Sostituto
On/Off	 Power	Menu Right	 Right
Mute	 Mute	Menu Off	 Exit
Update	 Media	Menu Down	 Down
Reveal	 Smart	Back	 Back
Txt Stop	 Stop	Volume+	 Vol +
Subt.List	 Subt	Chan.Up	 Ch +
Sleep Timer	 Sleep	Volume-	 Vol -
Return TV	 TV/R	Menu audio	 Dual
Menu video	 D. Menu	Chan.Down	 Ch -
Text	 Text	1	 1
Txt Expand	 Eject	2	 2
TV/AV	 AV	3	 3
Menu	 Menu	4	 4
Menu Up	 Up	5	 5
Display	 Info	6	 6
Menu Left	 Left	7	 7
OK Enter	 Ok	8	 8



Originale	Sostituto	Originale	Sostituto
On/Off	 Power	OK Enter	 Ok
Audio Off	 Mute	Return	 Back
Slow Down	 I<<	Menu Right	 Right
Subt.	 Subt	Menu Down	 Down
Auto/Track	 Green	Volume+	 Vol +
Slow Up	 >>I	Progr.	 Sleep
Rep/A-B	 +  Shift + Text	Next	 Ch +
Stop	 Stop	Volume-	 Vol -
Title	 List	Top Menu	 D. Menu
Zoom	 +  Shift + Eject	Prev.	 Ch -
Repeat/1/All	 Text	1	 1
Pause	 Pause	2	 2
DVD/TV	 AV	3	 3
Menu	 Menu	4	 4
Menu Up	 Up	5	 5
Display	 Info	6	 6
Menu Left	 Left	7	 7



Originale	Sostituto	Originale	Sostituto
8		8	8
9		9	9
+10			Guide
EQ			Media
0			0
C/CH			Pre Ch
Digest			Red
Record			Rec
Open/Close			Eject
Mode			Smart
Angle			TV/R
Rewind			<<
Play			Play
Clear/00:00			Exit
Audio			Dual
F.Forward			>>
NTSC/PAL			Format
		Setup	 Options
		3D	 3D

