

























Originale	Sostituto
 Power	 Power
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 FAV	 Pre Ch
 TXT	 Text
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue

Originale	Sostituto
 Exit	 Exit
 ?	 Dual
 @	 Shift + Media
 Menu	 Menu
 Back	 Back
 Tools	 Options
 Guide	 Guide
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 Vol+	 Vol +
 Vol-	 Vol -
 Mute	 Mute
 Source	 AV
 P+	 Ch +





Originale		Sostituto		Originale	Sostituto
	P-		Ch -		
	I<		I<<		
	>I		>>I		
	<<		<<		
	>>		>>		
	Rec		Rec		
	Play		Play		
	Pause		Pause		
	Stop		Stop		
	3D		3D		
	..OQ		Format		
	[...].		Subt		
	Netflix		Smart		
	My Media		Media		

