







































































Originale		Sostituto		Originale		Sostituto	
	Mute		Mute / Dimmer		9		9
	Up		Up		PP		Back / Return
	Power		Power		0		0
	Left		Left		-/--/Exit		Exit / Cancel / Clear
	Menu		Menu / Home		P+		CH+ / Page+
	Right		Right		Vol-		Vol-
	OK/Select		OK		Vol+		Vol+
	Down		Down		P-		CH- / Page-
	[i]/Info		Info / Angle		Swap/P<P		Fav / Marker / PC
	1		1		I-II		Audio / Lang I/II
	2		2		Tv/DTV		TV/Radio /
	3		3		AV/Source		AV / Input / RDS
	4		4		Red/↑		Red / Netflix / Search
	5		5		Green/↓		Green / APP / Repeat
	6		6		Yellow		Yellow / YouTube / Repeat
	7		7		Blue		Blue / Prime Video / Random
	8		8		[≡]/Text		Text / Goto



