

































Originale	Sostituto
 Power	 Power
 Mute	 Mute / Dimmer
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Audio	 Audio / Lang I/II
 Recall	 Back / Return
 Menu	 Menu / Home
 Exit	 Exit / Cancel / Clear
 Info	 Info / Angle

Originale	Sostituto
 EPG	 Guide / EPG / -/--
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 OK
 SAT	 Shift + 0
 FAV	 Fav / Marker / PC
 Tv/Radio	 TV/Radio /
 Subtitle	 Subtitle / EQ
 Find	 Smart / List
 Pg Up	 CH+ / Page+
 PgDn	 CH- / Page-
 Red	 Red / Netflix / Search
 Green	 Green / APP / Repeat
 Yellow	 Yellow / YouTube / Repeat
 Blue	 Blue / Prime Video / Random





Originale	Sostituto
	<< / Tune-
	>> / Tune+
	<< / Preset-
	>> / Preset+
	Play / Slow
	Pause / Step / Freeze
	Rec / Rec Mode
	Stop / Hold
	Text / Goto

Originale	Sostituto

