























































Originale	Sostituto	Originale	Sostituto
	Power		Power
	[i+]		Info
	TV/DTT		Smart
	Input		AV
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	[> <]		Format
	White		Pre Ch
	I/II/[≡i]		Dual
	Vol+		Vol +
	Vol-		Vol -
	Mute		Mute
	P+		Ch +
	P-		Ch -
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	[≡]		Text
	[≡+]/Status		3D
	[...]		Subt
	[≡?]/Skip		Options
	Menu		Menu
	Guide		Guide
	Nothing 3		Shift + 3
	Exit		Exit















































	Originale	Sostituto	Originale	Sostituto
	Power			
	P+			
	P-			
	Up			
	Down			
	Right			
	Left			
	Enter			
	Menu			
	Pause			
	Play			
	Stop			
	<<			
	>>			
	I<<			
	>>I			





Originale	Sostituto
 Power	 Power
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Vol+	 Vol +
 Vol-	 Vol -
 P+	 Ch +
 P-	 Ch -
 Menu	 Menu
 Up	 Up

Originale	Sostituto
 Down	 Down
 Right	 Right
 Left	 Left
 Enter	 Ok

