

























Originale	Sostituto
	AV / Input / RDS
	Power
	Display / Media
	Zoom / Size
	Shift + CH- /
	Shift + CH+ /
	Mute / Dimmer
	Text / Goto
	Sleep / Timer
	Smart / List
	Audio / Lang I/II
	Menu / Home
	D.Menu / Top
	Exit / Cancel / Clear
	Left
	Up
	Right

Originale	Sostituto
	OK
	Down
	Red / Netflix / Search
	Green / APP / Repeat
	Yellow / YouTube / Repeat
	Blue / Prime Video / Random
	Vol+
	CH+ / Page+
	Vol-
	Shift + Smart / List
	Shift + Display / Media
	CH- / Page-
	1
	2
	3
	4
	5







































































Originale	Sostituto
 Power	 Power
 Menu	 Menu / Home
 Left	 Left
 Up	 Up
 Right	 Right
 OK	 OK
 Down	 Down
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0

Originale	Sostituto
 Play	 Play / Slow
 Pause	 Pause / Step / Freeze
 Stop	 Stop / Hold
 <<	 << / Tune-
 >>	 >> / Tune+
 I<<	 I<< / Preset-
 >>I	 >>I / Preset+







































Originale	Sostituto
 Power STB	 Power
 Mute STB	 Mute / Dimmer
 Tv/AV STB	 AV / Input / RDS
 Menu STB	 Menu / Home
 Up STB	 Up
 Left STB	 Left
 OK STB	 OK
 Right STB	 Right
 Down STB	 Down
 Vol+ STB	 Vol+
 PR+ STB	 CH+ / Page+
 Vol- STB	 Vol-
 PR- STB	 CH- / Page-
 1 STB	 1
 2 STB	 2
 3 STB	 3
 4 STB	 4

Originale	Sostituto
 5 STB	 5
 6 STB	 6
 7 STB	 7
 8 STB	 8
 9 STB	 9
 0 STB	 0
 Power Cable	 Shift + Power
 Mute Cable	 Shift + Mute / Dimmer
 Menu Cable	 Shift + Menu /
 Up Cable	 Shift + Up
 OK Cable	 Shift + OK
 Down Cable	 Shift + Down
 Vol+ Cable	 Shift + Vol+
 PR+ Cable	 Shift + CH+ /
 Vol- Cable	 Shift + Vol-
 PR- Cable	 Shift + CH- /
 1 Cable	 Shift + 1





Originale	Sostituto
 Power VCR	 Power
 Tv/AV VCR	 AV / Input / RDS
 PR+ VCR	 CH+ / Page+
 PR- VCR	 CH- / Page-
 1 VCR	 1
 2 VCR	 2
 3 VCR	 3
 4 VCR	 4
 5 VCR	 5
 6 VCR	 6
 7 VCR	 7
 8 VCR	 8
 9 VCR	 9
 0 VCR	 0
 Play VCR	 Play / Slow
 Pause VCR	 Pause / Step / Freeze
 Stop VCR	 Stop / Hold

Originale	Sostituto
 Rec VCR	 Rec / Rec Mode
 << VCR	 << / Tune-
 >>	 >> / Tune+
 Power Audio	 Shift + Power
 Vol+ Audio	 Vol+
 Vol- Audio	 Vol-
 Mute Audio	 Mute / Dimmer

