








































































Originale		Sostituto		Originale		Sostituto	
	Power		Power		Menu		Menu
	Mute		Mute		Exit		Exit
	Picture	 + 	Shift + Format		1		1
	Sound	 + 	Shift + Dual		2		2
	Aspect		Format		3		3
	Sleep		Sleep		4		4
	Subtitle		Subt		5		5
	CH.List		List		6		6
	FAV		Media		7		7
	TV/Radio		Pre Ch		8		8
	Input		TV/R		9		9
	Up		AV		0		0
	Left		Back		Recall		Back
	OK		Info		Display		Info
	Right		Vol +		Vol+		Vol +
	Down		Vol -		Vol-		Vol -
			Ch +		CH+		Ch +



