





























































































Originale	Sostituto
 Sleep	 Sleep / Timer
 On/Standby	 Power
 CBL/SAT	 0
 DVD	 2
 Blu-ray	 4
 Game	 Fav / Marker / PC
 AUX	 7
 Media Player	 Display / Media
 TV Audio	 1
 CD	 3
 Tuner	 6
 iPod/USB	 8
 Phono	 Guide / EPG / -/--
 M-XPort	 5
 Network	 9
 Internet Radio	 Smart / List
 CH+	 CH+ / Page+

Originale	Sostituto
 Vol+	 Vol+
 CH-	 CH- / Page-
 Mute	 Mute / Dimmer
 Vol-	 Vol-
 Info	 Info / Angle
 Option	 Shift + Setup / OPT / Tools
 Option	 Menu / Home
 Up	 Up
 Left	 Left
 Enter	 OK
 Right	 Right
 Back	 Back / Return
 Down	 Down
 Setup	 Setup / OPT /
 I<</Tune-	 I<< / Preset-
 I<</Tune-	 << / Tune-
 Play / Pause	 Play / Slow





Originale	Sostituto
 Sleep	 Sleep / Timer
 On/Standby	 Power
 CBL/SAT	 0
 DVD	 2
 Blu-ray	 4
 Game	 Fav / Marker / PC
 AUX	 7
 Media Player	 Display / Media
 TV Audio	 1
 CD	 3
 Tuner	 6
 iPod/USB	 8
 Phono	 Guide / EPG / -/-
 M-XPort	 5
 Network	 9
 Internet Radio	 Smart / List
 CH+	 CH+ / Page+

Originale	Sostituto
 Vol+	 Vol+
 CH-	 CH- / Page-
 Mute	 Mute / Dimmer
 Vol-	 Vol-
 Option	 Setup / OPT /
 Option	 Menu / Home
 Up	 Up
 Left	 Left
 Enter	 OK
 Right	 Right
 Back	 Back / Return
 Down	 Down
 I<</Tune-	 I<< / Preset-
 I<</Tune-	 << / Tune-
 Play / Pause	 Play / Slow
 Play / Pause	 Pause / Step / Freeze
 >>I/Tune+	 >>I / Preset+



