









































Originale	Sostituto
	 Power
	 Stop
	 Pause
	 Rec
	 <<<
	 Play
	 >>>
	 Format
	 TV/R
	 Menu
	 Guide
	 List
	 AV
	 Smart
	 Shift + Smart
	 Exit
	 Red

Originale	Sostituto
	 Green
	 Yellow
	 Blue
	 Info
	 Options
	 Back
	 3D
	 Up
	 Down
	 Right
	 Left
	 Media
	 Ok
	 Vol +
	 Vol -
	 Mute
	 Ch +



