
















































Originale	Sostituto
 Power	 Power
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 TV / Radio	 TV/R
 ←PR	 Back
 EPG	 Guide
 Menu	 Menu
 Up / PR+	 Up

Originale	Sostituto
 Up / PR+	 Ch +
 Down / PR-	 Down
 Down / PR-	 Ch -
 Right / Vol+	 Right
 Right / Vol+	 Vol +
 Left / Vol-	 Left
 Left / Vol-	 Vol -
 OK / List	 Ok
 OK / List	 List
 Info	 Info
 Exit	 Exit
 Red / Audio	 Red
 Red / Audio	 Dual
 Green / TXT	 Green
 Green / TXT	 Text
 Yellow / Subtitle	 Yellow
 Yellow / Subtitle	 Subt



