





Originale	Sostituto
 Power	 Power
 Mute	 Mute
 Play / Pause	 Play
 Play / Pause	 Pause
 Stop	 Stop
 I> Step	 Shift + Pause
 Rec / B.Mark	 Rec
 << / F1	 <<
 >> / F2	 >>
 I<< / F3	 I<<
 >>I / F4	 >>I
 OPT	 Options
 EPG / Seek	 Guide
 FAV / Repeat	 Shift + Text
 FAV / Repeat	 Pre Ch
 SAT / (A-B)	 AV
 RED / SUB.T	 Red

Originale	Sostituto
 RED / SUB.T	 Subt
 Green / Txt	 Green
 Green / Txt	 Text
 Yellow / Timer	 Yellow
 Yellow / Timer	 Shift + AV
 Blue / Audio	 Blue
 Blue / Audio	 Dual
 Menu	 Menu
 Exit	 Exit
 Up	 Up
 Right	 Right
 Down	 Down
 Left	 Left
 OK	 Ok
 Recall	 Back
 Info	 Info
 Vol +	 Vol +





Originale	Sostituto
Vol -	Vol -
APPS	Smart
APPS	+  Shift + Media
USB	Media
CH + / Page +	Ch +
CH - / Page -	Ch -
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0 / Zoom	0
0 / Zoom	Eject

Originale	Sostituto
VF	Format
TV / Radio	TV/R

