




















Originale	Sostituto	Originale	Sostituto
	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Source		AV
	ATV/DTV/Content Menu		Smart
	Vol+		Vol +
	Vol-		Vol -
	P+		Ch +
	P-		Ch -

Originale	Sostituto	Originale	Sostituto
	Mute		Mute
	Guide/Top		Media
	Exit/Return		Exit
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	Menu/DVD		Menu
	Tv/FAV/Radio/Set		TV/R
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	[<>]		Format
	<[/]>		3D
	Subtitle		Subt









































































Originale		Sostituto		Originale		Sostituto	
	Text		Text				
	II/II>/[▼]		Pause				
	[i+]/[≡i]		Info				
	O)I/II		Dual				
	Stop		Stop				
	Play/[≡o]		Play				
	Eject		Eject				
	I<</[≡?]		I<<				
	<</[≡+]		<<				
	>>/[≡◇]		>>				
	>>I/[O]/[≡X]		>>I				
	AD	 + 	Shift + Subt				
	Audio	 + 	Shift + Dual				





Originale		Sostituto		Originale		Sostituto	
	←[/]→		3D		Menu/DVD		Menu
	Power		Power		Tv/FAV/Radio/Set		TV/R
	1		1		Guide/Top		Guide
	2		2		[<>]		Format
	3		3		Text		Text
	4		4		Subtitle		Subt
	5		5		O) /II		Dual
	6		6		[i+]/[≡i]		Info
	7		7		OK		Ok
	8		8		Up		Up
	9		9		Down		Down
	0		0		Right		Right
	Source		AV		Left		Left
	Mute		Mute		/II>/[▼]		Pause
	Vol+		Vol +		Play/[≡o]		Play
	Vol-		Vol -		Stop		Stop
	Exit/Return		Exit		Eject		Eject











































Originale		Sostituto		Originale		Sostituto	
	I<</[≡?]		I<<				
	<</[≡+]		<<				
	>>/[≡◇]		>>				
	>>I/[O]/[≡X]		>>I				
	Audio	 + 	Shift + Dual				





Originale	Sostituto	Originale	Sostituto
	Power		Power
	←[/]→		3D
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Source		AV
	ATV/DTV/Content Menu		Smart
	Vol+		Vol +
	Vol-		Vol -
	P+		Ch +

Originale	Sostituto	Originale	Sostituto
	P-		Ch -
	Mute		Mute
	Guide/Top		Guide
	Exit/Return		Exit
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	Menu/DVD		Menu
	Tv/FAV/Radio/Set		TV/R
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	Text		Text
	[<>]		Format



