



















































Originale		Sostituto		Originale		Sostituto	
	Power		Power		Dn/>>>I		Ch -
	Tv-Out		AV		Menu		Menu
	1		1		>>		>>
	2		2		<<		<<
	3		3		Player		Yellow
	4		4		Stop		Stop
	5		5		Enter		Ok
	6		6		Right		Right
	7		7		Left		Left
	8		8		Up		Up
	9		9		Down		Down
	0		0		Mute		Mute
	Subtitle		Subt		Zoom		Shift + Eject
	Audio		Dual		Repeat		Text
	Vol+		Vol +		Setup		Options
	Vol-		Vol -		Display		Shift + Info
	Up/ <<		Ch +		Rotate		Back



