| Originale | | Sostituto | |
|---|---|---|---|
| SYSTEM ON | System Power | | Power |
| POWER OFF | System Power Off | SHIFT + | Shift + Power |
| SOURCE ON/OFF | Source On/Off | NETFLIX SEARCH | Red / Netflix / Search |
| SOURCE ON/OFF | Source On/Off | APP REPEAT | Green / APP / Repeat |
| SOURCE ON/OFF | Source On/Off | Prime Video RANDOM | Blue / Prime Video / Random |
| SOURCE ON/OFF | Source On/Off CD | YouTube REPEAT A-B | Yellow / YouTube / Repeat |
| SOURCE ON/OFF | Source On/Off | SHIFT + NETFLIX SEARCH | Shift + Red / Netflix / |
| SOURCE ON/OFF | Source On/Off | SHIFT + APP REPEAT | Shift + Green / APP / |
| SOURCE ON/OFF | Source On/Off | SHIFT + YouTube REPEAT A-B | Shift + Yellow / YouTube / |
| SOURCE ON/OFF | Source On/Off MD | SHIFT + Prime Video RANDOM | Shift + Blue / Prime |
| SOURCE ON/OFF | Source On/Off | SHIFT + PC FAV MARKER | Shift + Fav / Marker / PC |
| PHONO | Phono | SHIFT + TV 1 | Shift + 1 |
| CD | CD | SHIFT + CD-STB 3 | Shift + 3 |
| TUNER | Tuner | SHIFT + TUNER 6 | Shift + 6 |
| CD-R | CD-R | SHIFT + DVD 2 | Shift + 2 |
| AUX 1 | AUX1 | SHIFT + AUX-HDD 7 | Shift + 7 |
| AUX 2 | AUX2 | SHIFT + USB 8 | Shift + 8 |

| Originale | | Sostituto | |
|---|---|---|---|
| TAPE | Tape | SHIFT + TAPE 5 | Shift + 5 |
| MD | MD | SHIFT + VIDEO 4 | Shift + 4 |
| 1 | 1 Tuner | TV 1 | 1 |
| 2 | 2 Tuner | DVD 2 | 2 |
| 3 | 3 Tuner | CD-STB 3 | 3 |
| A.F/P | A. F/P Tuner | -/-- GUIDE EPG | Guide / EPG / -/-- |
| 4 | 4 Tuner | VIDEO 4 | 4 |
| 5 | 5 Tuner | TAPE 5 | 5 |
| 6 | 6 Tuner | TUNER 6 | 6 |
| B.-/-- | B. -/-- Tuner | PC FAV MARKER | Fav / Marker / PC |
| 7 | 7 Tuner | AUX-HDD 7 | 7 |
| 8 | 8 Tuner | USB 8 | 8 |
| 9 | 9 Tuner | BLUETOOTH 9 | 9 |
| MODE | Mode Tuner | LIST SMART | Smart / List |
| - | - Tuner | CH PAGE - | CH- / Page- |
| 0 | 0 Tuner | HDMI-SAT 0 | 0 |
| + | + Tuner | + CH PAGE | CH+ / Page+ |

| Originale | Sostituto | Originale | Sostituto |
|---|---|---|---|
| MEMO Memo Tuner | MEDIA DISPLAY Display / Media | | |
| SCROLL Scroll Tuner | RETURN BACK Back / Return | | |
| CANCEL Cancel Tuner | CLEAR EXIT CANCEL Exit / Cancel / Clear | | |
| 1-MOD TEXT Text / Mode 1 | GOTO TEXT Text / Goto | | |
| ODE-2 TIME Time/Mode 2 | TIMER SLEEP Sleep / Timer | | |
| I<< Tuner | PRESET- I<< / Preset- | | |
| >>I Tuner | PRESET+ >>I / Preset+ | | |
| MUTE Mute | DIMMER MUTE Mute / Dimmer | | |
| << Tuner | TUNE- << / Tune- | | |
| >> Tuner | TUNE+ >> / Tune+ | | |
| VOLUME Vol + | VOL + Vol + | | |
| VOLUME Vol - | VOL - Vol - | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

| Originale | | Sostituto | |
|---|---|---|---|
| SYSTEM ON | System Power | | Power |
| POWER OFF | System Power Off | SHIFT + | Shift + Power |
| SOURCE ON/OFF | Source On/Off | SHIFT + NETFLIX SEARCH | Shift + Red / Netflix / |
| SOURCE ON/OFF | Source On/Off | NETFLIX SEARCH | Red / Netflix / Search |
| SOURCE ON/OFF | Source On/Off | APP REPEAT | Green / APP / Repeat |
| SOURCE ON/OFF | Source On/Off CD | YouTube REPEAT A-B | Yellow / YouTube / Repeat |
| SOURCE ON/OFF | Source On/Off | Prime Video RANDOM | Blue / Prime Video / Random |
| SOURCE ON/OFF | Source On/Off | SHIFT + APP REPEAT | Shift + Green / APP / |
| SOURCE ON/OFF | Source On/Off | SHIFT + YouTube REPEAT A-B | Shift + Yellow / YouTube / |
| SOURCE ON/OFF | Source On/Off MD | SHIFT + Prime Video RANDOM | Shift + Blue / Prime |
| SOURCE ON/OFF | Source On/Off | SHIFT + PC FAV MARKER | Shift + Fav / Marker / PC |
| PHONO | Phono | SHIFT + TV 1 | Shift + 1 |
| CD | CD | SHIFT + CD-STB 3 | Shift + 3 |
| TUNER | Tuner | SHIFT + TUNER 6 | Shift + 6 |
| CD-R | CD-R | SHIFT + DVD 2 | Shift + 2 |
| AUX 1 | AUX1 | SHIFT + AUX-HDD 7 | Shift + 7 |
| AUX 2 | AUX2 | SHIFT + USB 8 | Shift + 8 |

| Originale | | Sostituto | |
|---|---|---|---|
| TAPE | Tape | SHIFT + TAPE 5 | Shift + 5 |
| MD | MD | SHIFT + VIDEO 4 | Shift + 4 |
| 1 | 1 CDR | TV 1 | 1 |
| 2 | 2 CDR | DVD 2 | 2 |
| 3 | 3 CDR | CD-STB 3 | 3 |
| 4 | 4 CDR | VIDEO 4 | 4 |
| 5 | 5 CDR | TAPE 5 | 5 |
| 6 | 6 CDR | TUNER 6 | 6 |
| 7 | 7 CDR | AUX-HDD 7 | 7 |
| 8 | 8 CDR | USB 8 | 8 |
| 9 | 9 CDR | BLUETOOTH 9 | 9 |
| MODE | Mode CDR | LIST SMART | Smart / List |
| - | - CDR | CH PAGE - | CH- / Page- |
| 0 | 0 CDR | HDMI-SAT 0 | 0 |
| + | + CDR | CH PAGE + | CH+ / Page+ |
| MEMO | Memo CDR | MEDIA DISPLAY | Display / Media |
| SCROLL | Scroll CDR | RETURN BACK | Back / Return |

| Originale | Sostituto | Originale | Sostituto |
|---|---|---|---|
| CANCEL Cancel CDR | CLEAR EXIT CANCEL Exit / Cancel / Clear | | |
| 1-MODE TEXT Text / Mode 1 | GOTO TEXT Text / Goto | | |
| MODE-2 TIME Time / Mode 2 | TIMER SLEEP Sleep / Timer | | |
| I<< CDR | PRESET- I<< / Preset- | | |
| Play CDR | SLOW Play / Slow | | |
| >>I CDR | PRESET+ >>I / Preset+ | | |
| MUTE Mute | DIMMER MUTE Mute / Dimmer | | |
| << CDR | TUNE- << / Tune- | | |
| Stop CDR | HOLD Stop / Hold | | |
| >> CDR | TUNE+ >> / Tune+ | | |
| VOLUME Vol + | VOL Vol + | | |
| Pause CDR | STEP-FREEZE Pause / Step / Freeze | | |
| OPEN/ CLOSE Open/Close | SURROUND Eject / Surround | | |
| VOLUME Vol - | VOL Vol - | | |
| | | | |
| | | | |
| | | | |

| Originale | | Sostituto | |
|---|---|---|---|
| SYSTEM ON | System Power | | Power |
| POWER OFF | System Power Off | SHIFT + | Shift + Power |
| SOURCE ON/OFF | Source On/Off | SHIFT + YouTube REPEAT A-B | Shift + Yellow / YouTube / |
| SOURCE ON/OFF | Source On/Off | NETFLIX SEARCH | Red / Netflix / Search |
| SOURCE ON/OFF | Source On/Off | APP REPEAT | Green / APP / Repeat |
| SOURCE ON/OFF | Source On/Off CD | YouTube REPEAT A-B | Yellow / YouTube / Repeat |
| SOURCE ON/OFF | Source On/Off | Prime Video RANDOM | Blue / Prime Video / Random |
| SOURCE ON/OFF | Source On/Off | SHIFT + NETFLIX SEARCH | Shift + Red / Netflix / |
| SOURCE ON/OFF | Source On/Off | SHIFT + APP REPEAT | Shift + Green / APP / |
| SOURCE ON/OFF | Source On/Off MD | SHIFT + Prime Video RANDOM | Shift + Blue / Prime |
| SOURCE ON/OFF | Source On/Off | SHIFT + PC FAV MARKER | Shift + Fav / Marker / PC |
| PHONO | Phono | SHIFT + TV 1 | Shift + 1 |
| CD | CD | SHIFT + CD-STB 3 | Shift + 3 |
| TUNER | Tuner | SHIFT + TUNER 6 | Shift + 6 |
| CD-R | CD-R | SHIFT + DVD 2 | Shift + 2 |
| AUX 1 | AUX1 | SHIFT + AUX-HDD 7 | Shift + 7 |
| AUX 2 | AUX2 | SHIFT + USB 8 | Shift + 8 |

| Originale | | Sostituto | |
|---|---|---|---|
| TAPE | Tape | SHIFT + TAPE 5 | Shift + 5 |
| MD | MD | SHIFT + VIDEO 4 | Shift + 4 |
| 1 | 1 Tape | TV 1 | 1 |
| 2 | 2 Tape | DVD 2 | 2 |
| 3 | 3 Tape | CD-STB 3 | 3 |
| A.F/P | A. F/P Tape | -/-- GUIDE EPG | Guide / EPG / -/-- |
| 4 | 4 Tape | VIDEO 4 | 4 |
| 5 | 5 Tape | TAPE 5 | 5 |
| 6 | 6 Tape | TUNER 6 | 6 |
| B.-/-- | B. -/-- Tape | PC FAV MARKER | Fav / Marker / PC |
| 7 | 7 Tape | AUX-HDD 7 | 7 |
| 8 | 8 Tape | USB 8 | 8 |
| 9 | 9 Tape | BLUETOOTH 9 | 9 |
| MODE | Mode Tape | LIST SMART | Smart / List |
| - | - Tape | CH PAGE - | CH- / Page- |
| 0 | 0 Tape | HDMI-SAT 0 | 0 |
| + | + Tape | + CH PAGE | CH+ / Page+ |

| Originale | Sostituto | Originale | Sostituto |
|---|---|---|---|
| Memo Tape | Display / Media | | |
| Cancel Tape | Exit / Cancel / Clear | | |
| Text / Mode 1 | Text / Goto | | |
| Time / Mode 2 | Sleep / Timer | | |
| I<< Tape | I<< / Preset- | | |
| Play Tape | Play / Slow | | |
| >>I Tape | >>I / Preset+ | | |
| Mute | Mute / Dimmer | | |
| << Tape | << / Tune- | | |
| Stop Tape | Stop / Hold | | |
| >> Tape | >> / Tune+ | | |
| Vol + | Vol + | | |
| <> Tape | Rec / Rec Mode | | |
| Pause Tape | Pause / Step / Freeze | | |
| Open/Close | Eject / Surround | | |
| Vol - | Vol - | | |

| Originale | | Sostituto | |
|---|---|---|---|
| SYSTEM ON | System Power | | Power |
| POWER OFF | System Power Off | SHIFT + | Shift + Power |
| SOURCE ON/OFF | Source On/Off | NETFLIX SEARCH | Red / Netflix / Search |
| SOURCE ON/OFF | Source On/Off CD | YouTube REPEAT A-B | Yellow / YouTube / Repeat |
| SOURCE ON/OFF | Source On/Off | APP REPEAT | Green / APP / Repeat |
| SOURCE ON/OFF | Source On/Off | Prime Video RANDOM | Blue / Prime Video / Random |
| SOURCE ON/OFF | Source On/Off | SHIFT + NETFLIX SEARCH | Shift + Red / Netflix / |
| SOURCE ON/OFF | Source On/Off | SHIFT + APP REPEAT | Shift + Green / APP / |
| SOURCE ON/OFF | Source On/Off | SHIFT + YouTube REPEAT A-B | Shift + Yellow / YouTube / |
| SOURCE ON/OFF | Source On/Off MD | SHIFT + Prime Video RANDOM | Shift + Blue / Prime |
| SOURCE ON/OFF | Source On/Off | SHIFT + PC FAV MARKER | Shift + Fav / Marker / PC |
| PHONO | Phono | SHIFT + TV 1 | Shift + 1 |
| CD | CD | SHIFT + CD-STB 3 | Shift + 3 |
| TUNER | Tuner | SHIFT + TUNER 6 | Shift + 6 |
| CD-R | CD-R | SHIFT + DVD 2 | Shift + 2 |
| AUX 1 | AUX1 | SHIFT + AUX-HDD 7 | Shift + 7 |
| AUX 2 | AUX2 | SHIFT + USB 8 | Shift + 8 |

| Originale | | Sostituto | |
|---|---|---|---|
| TAPE | Tape | SHIFT + TAPE 5 | Shift + 5 |
| MD | MD | SHIFT + VIDEO 4 | Shift + 4 |
| 1 | 1 CD | TV 1 | 1 |
| 2 | 2 CD | DVD 2 | 2 |
| 3 | 3 CD | CD-STB 3 | 3 |
| A.F/P | A. F/P CD | -/-- GUIDE EPG | Guide / EPG / -/-- |
| 4 | 4 CD | VIDEO 4 | 4 |
| 5 | 5 CD | TAPE 5 | 5 |
| 6 | 6 CD | TUNER 6 | 6 |
| B.-/-- | B. -/-- CD | PC FAV MARKER | Fav / Marker / PC |
| 7 | 7 CD | AUX-HDD 7 | 7 |
| 8 | 8 CD | USB 8 | 8 |
| 9 | 9 CD | BLUETOOTH 9 | 9 |
| MODE | Mode CD | LIST SMART | Smart / List |
| - | - CD | CH PAGE - | CH- / Page- |
| 0 | 0 CD | HDMI-SAT 0 | 0 |
| + | + CD | + CH PAGE | CH+ / Page+ |

| Originale | | Sostituto | | Originale | | Sostituto | |
|---|---|---|---|---|---|---|---|
| MEMO | Memo CD | MEDIA DISPLAY | Display / Media | | | | |
| SCROLL | Scroll CD | RETURN BACK | Back / Return | | | | |
| CANCEL | Cancel CD | CLEAR EXIT CANCEL | Exit / Cancel / Clear | | | | |
| 1-MOD TEXT | Text / Mode 1 CD | GOTO TEXT | Text / Goto | | | | |
| ODE-2 TIME | Time / Mode 2 CD | TIMER SLEEP | Sleep / Timer | | | | |
| ⏮ | I<< CD | PRESET- ⏮ | I<< / Preset- | | | | |
| ▶ | Play CD | SLOW ▶ | Play / Slow | | | | |
| ⏭ | >>I CD | PRESET+ ⏭ | >>I / Preset+ | | | | |
| MUTE | Mute | DIMMER MUTE | Mute / Dimmer | | | | |
| ◀◀ | << CD | TUNE- ◀◀ | << / Tune- | | | | |
| ■ | Stop CD | HOLD ■ | Stop / Hold | | | | |
| ▶▶ | >> CD | TUNE+ ▶▶ | >> / Tune+ | | | | |
| ▲ VOLUME | Vol + | + VOL | Vol + | | | | |
| ⏸ | Pause CD | STEP-FREEZE ⏸ | Pause / Step / Freeze | | | | |
| OPEN/ CLOSE | Open/Close CD | SURROUND ⏏ | Eject / Surround | | | | |
| VOLUME ▼ | Vol - | VOL − | Vol - | | | | |