Originale		Sostituto		Originale		Sostituto	
	Power		Power	MENU SETTINGS	Menu Settings	HOME MENU	Menu / Home
DELETE MUTE	Mute/Delete	DIMMER MUTE	Mute / Dimmer		Up		Up
	Play	SLOW	Play / Slow	INFO	Info	ANGLE INFO	Info / Angle
	Pause	STEP-FREEZE	Pause / Step / Freeze		Left		Left
	Stop	HOLD	Stop / Hold	OK ENTER	OK/Enter	OK	OK
	<<	TUNE-	<< / Tune-		Right		Right
	>>	TUNE+	>> / Tune+	EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
SWAP	Swap	TITLE SOUND	Sound / Title		Down		Down
SAP	SAP	LANG I/II AUDIO	Audio / Lang I/II		Back	RETURN BACK	Back / Return
SIMPLINK	Simplink	EQ SUBTITLE	Subtitle / EQ	VOL	Vol +	VOL	Vol +
PIP	PIP	FORMAT PICTURE	Picture / Format	CH	CH+	CH PAGE	CH+ / Page+
PIP INPUT	PIP Input	SIZE ZOOM	Zoom / Size	VOL	Vol -	VOL	Vol -
TIMER	Timer	TIMER SLEEP	Sleep / Timer	PORTAL	Portal	MEDIA DISPLAY	Display / Media
Q.MENU	Q.Menu	TOP MENU D.MENU	D.Menu / Top	CH	CH-	CH PAGE	CH- / Page-
CHAR/NUM CC	CC/Char/Num	OPT-TOOLS SETUP	Setup / OPT /	1	1	TV 1	1
	--	GOTO TEXT	Text / Goto	2abc	2	DVD 2	2
INPUT	Input	RDS AV INPUT	AV / Input / RDS	3def	3	CD-STB 3	3

Originale		Sostituto		Originale	Sostituto
4ghi	4	VIDEO 4	4		
5jkl	5	TAPE 5	5		
6mno	6	TUNER 6	6		
7pqrs	7	AUX - HDD 7	7		
8tuv	8	USB 8	8		
9wxyz	9	BLUETOOTH 9	9		
GUIDE	Guide	-/-- GUIDE EPG	Guide / EPG / -/--		
0	0	HDMI - SAT 0	0		
MARK	Mark	PC FAV MARKER	Fav / Marker / PC		
	Red	NETFLIX SEARCH	Red / Netflix / Search		
	Green	APP REPEAT	Green / APP / Repeat		
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
	Blue	Prime Video RANDOM	Blue / Prime Video / Random		
PIPCH+	PIP CH+	SHIFT + CH PAGE +	Shift + CH+ /		
PIPCH-	PIP CH-	SHIFT + CH PAGE -	Shift + CH- /		
FLASHBK	Flashbk	SHIFT + PC FAV MARKER	Shift + Fav / Marker / PC		

Originale		Sostituto	
	Power		Power
DELETE MUTE	Mute/Delete	DIMMER MUTE	Mute / Dimmer
	Play	SLOW	Play / Slow
	Pause	STEP-FREEZE	Pause / Step / Freeze
	Stop	HOLD	Stop / Hold
	<<	TUNE-	<< / Tune-
	>>	TUNE+	>> / Tune+
MENU SETTINGS	Menu Settings	HOME MENU	Menu / Home
	Up		Up
	Left		Left
OK ENTER	OK/Enter	OK	OK
	Right		Right
	Down		Down
VOL +	Vol +	VOL +	Vol +
CH	CH+	CH PAGE +	CH+ / Page+
VOL -	Vol -	VOL -	Vol -
CH	CH-	CH PAGE -	CH- / Page-

Originale		Sostituto	
1	1	TV 1	1
2abc	2	DVD 2	2
3def	3	CD-STB 3	3
4ghi	4	VIDEO 4	4
5jkl	5	TAPE 5	5
6mno	6	TUNER 6	6
7pqrs	7	AUX-HDD 7	7
8tuv	8	USB 8	8
9wxyz	9	BLUETOOTH 9	9
0	0	HDMI-SAT 0	0