Originale		Sostituto	
ON/STANDBY	On/Standby		Power
DISPLAY	Display	MEDIA DISPLAY	Display / Media
DVD/BD	DVD / BD	SHIFT + DVD 2	Shift + 2
VCR/DVR	VCR / DVR	SHIFT + VIDEO 4	Shift + 4
CBL/SAT	CBL/SAT	SHIFT + HDMI - SAT 0	Shift + 0
GAME	Game	SHIFT + BLUETOOTH 9	Shift + 9
AUX	AUX	SHIFT + AUX - HDD 7	Shift + 7
TV/TAPE	TV / TAPE	SHIFT + TAPE 5	Shift + 5
TV/TAPE	TV / TAPE	SHIFT + TV 1	Shift + 1
TUNER	TUNER	SHIFT + TUNER 6	Shift + 6
PORT	PORT	SHIFT + USB 8	Shift + 8
CD	CD	SHIFT + CD - STB 3	Shift + 3
MUTING	Muting	DIMMER MUTE	Mute / Dimmer
CH DISC	CH/Disc/Album	CH PAGE +	CH+ / Page+
VOL	Vol +	VOL +	Vol +
ALBUM	CH/Disc/Album-	CH PAGE −	CH- / Page-
VOL	Vol -	VOL −	Vol -

Originale		Sostituto	
	Up		Up
PLAYLIST /CATEGORY	Left		Left
ENTER	Enter	OK	OK
PLAYLIST /CATEGORY	Right		Right
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
	Down		Down
RETURN	Return	RETURN BACK	Back / Return
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II
	I<<	PRESET-	I<< / Preset-
	>>I	PRESET+	>>I / Preset+
	<<	TUNE-	<< / Tune-
	Play	SLOW	Play / Slow
	>>	TUNE+	>> / Tune+
	Pause	STEP - FREEZE	Pause / Step / Freeze
	Stop	HOLD	Stop / Hold
MOVIE/TV SEARCH	Movie Tv	NETFLIX SEARCH	Red / Netflix / Search
MUSIC REPEAT	Music	APP REPEAT	Green / APP / Repeat

Originale		Sostituto		Originale	Sostituto
GAME RANDOM	Game	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
STEREO PLAY MODE	Stereo	Prime Video RANDOM	Blue / Prime Video / Random		
1	1	TV 1	1		
2	2	DVD 2	2		
3	3	CD - STB 3	3		
4	4	VIDEO 4	4		
5	5	TAPE 5	5		
6	6	TUNER 6	6		
7	7	AUX - HDD 7	7		
8	8	USB 8	8		
9	9	BLUETOOTH 9	9		
+10 D.TUN DIMMER	+10/--/---10/Dimmer/D.Tun	-/-- GUIDE EPG	Guide / EPG / -/--		
0	0/11	HDMI - SAT 0	0		
CLR SLEEP	CLR/Sleep/12	PC FAV MARKER	Fav / Marker / PC		
CLR SLEEP	CLR/Sleep/12	TIMER SLEEP	Sleep / Timer		
CLR SLEEP	CLR/Sleep/12	CLEAR EXIT CANCEL	Exit / Cancel / Clear		

Originale		Sostituto	
ON/STANDBY	Power BD/DVD		Power
DVD/BD	DVD/BD	SMART	Smart / List
CBL/SAT	CBL/SAT	DISPLAY	Display / Media
VOL	Vol + Receiver	VOL +	Vol +
VOL	Vol - Receiver	VOL −	Vol -
GUIDE/TOP MENU	Top Menu	D.MENU	D.Menu / Top
	Up BD/DVD		Up
PREV CH/MENU	Menu BD/DVD	MENU	Menu / Home
PLAYLIST /CATEGORY	Left BD/DVD		Left
ENTER	Enter BD/DVD	OK	OK
PLAYLIST /CATEGORY	Right BD/DVD		Right
SETUP	Setup BD/DVD	SETUP	Setup / OPT /
	Down BD/DVD		Down
RETURN	Return BD/DVD	BACK	Back / Return
AUDIO	Audio BD/DVD	AUDIO	Audio / Lang I/II
	I<< BD/DVD	PRESET-	I<< / Preset-
	>>I BD/DVD	PRESET+	>>I / Preset+

Originale		Sostituto	
	<< BD/DVD	TUNE-	<< / Tune-
	Play BD/DVD	SLOW	Play / Slow
	>> BD/DVD	TUNE+	>> / Tune+
	Pause BD/DVD	STEP-FREEZE	Pause / Step / Freeze
	Stop BD/DVD	HOLD	Stop / Hold
MOVIE/TV SEARCH	Search BD/DVD	NETFLIX SEARCH	Red / Netflix / Search
MUSIC REPEAT	Repeat BD/DVD	APP REPEAT	Green / APP / Repeat
GAME RANDOM	Random	Prime Video RANDOM	Blue / Prime Video / Random
STEREO PLAY MODE	Play Mode	YouTube REPEAT A-B	Yellow / YouTube / Repeat
1	1 BD/DVD	TV 1	1
2	2 BD/DVD	DVD 2	2
3	3 BD/DVD	CD-STB 3	3
4	4 BD/DVD	VIDEO 4	4
5	5 BD/DVD	TAPE 5	5
6	6 BD/DVD	TUNER 6	6
7	7 BD/DVD	AUX-HDD 7	7
8	8 BD/DVD	USB 8	8

Originale		Sostituto	
9	9 BD/DVD	BLUETOOTH 9	9
+10 DIMMER	+10/--/--10	-/-- GUIDE EPG	Guide / EPG / -/--
0	0/11 BD/DVD	HDMI - SAT 0	0
CLR SLEEP	CLR/12 BD/DVD	PC FAV MARKER	Fav / Marker / PC
CLR SLEEP	CLR/12 BD/DVD	CLEAR EXIT CANCEL	Exit / Cancel / Clear
ON/STANDBY	Power CBL/SAT	SHIFT +	Shift + Power
CH DISC	CH Disc/Album+ CBL/SAT	SHIFT + CH PAGE +	Shift + CH+ /
ALBUM	CH Disc/Album- CBL/SAT	SHIFT + CH PAGE -	Shift + CH- /
GUIDE/TOP MENU	Guide CBL/SAT	SHIFT + -/-- GUIDE EPG	Shift + Guide / EPG / -/--
	Up CBL/SAT	SHIFT +	Shift + Up
PREV CH/MENU VIDEO	Menu/Prev CH CBL/SAT	SHIFT + HOME MENU	Shift + Menu /
PLAYLIST /CATEGORY	Left CBL/SAT	SHIFT +	Shift + Left
ENTER	Enter CBL/SAT	SHIFT + OK	Shift + OK
PLAYLIST /CATEGORY	Right CBL/SAT	SHIFT +	Shift + Right
SETUP	Setup CBL/SAT	SHIFT + OPT-TOOLS SETUP	Shift + Setup / OPT / Tools
	Down CBL/SAT	SHIFT +	Shift + Down
RETURN	Return CBL/SAT	SHIFT + RETURN BACK	Shift + Back / Return

Originale		Sostituto	
<<	<< CBL/SAT	SHIFT + TUNE-	Shift + << /
►	Play CBL/SAT	SHIFT + SLOW ▶	Shift + Play /
>>	>> CBL/SAT	SHIFT + TUNE+	Shift + >> /
❚❚	Pause CBL/SAT	SHIFT + STEP - FREEZE ❚❚	Shift + Pause / Step /
■	Stop CBL/SAT	SHIFT + HOLD ■	Shift + Stop /
MOVIE/TV SEARCH	Movie Tv/Search CBL/SAT	SHIFT + NETFLIX SEARCH	Shift + Red / Netflix /
LISTENI MUSIC REPEAT	Music/Repeat CBL/SAT	SHIFT + APP REPEAT	Shift + Green / APP /
GAME RANDOM	Game/Random	SHIFT + YouTube REPEAT A-B	Shift + Yellow / YouTube /
STEREO PLAY MODE	Stereo/Play Mode CBL/SAT	SHIFT + Prime Video RANDOM	Shift + Blue / Prime
1	1 CBL/SAT	SHIFT + TV 1	Shift + 1
2	2 CBL/SAT	SHIFT + DVD 2	Shift + 2
3	3 CBL/SAT	SHIFT + CD - STB 3	Shift + 3
4	4 CBL/SAT	SHIFT + VIDEO 4	Shift + 4
5	5 CBL/SAT	SHIFT + TAPE 5	Shift + 5
6	6 CBL/SAT	SHIFT + TUNER 6	Shift + 6
7	7 CBL/SAT	SHIFT + AUX - HDD 7	Shift + 7
8	8 CBL/SAT	SHIFT + USB 8	Shift + 8

Originale	Sostituto	Originale	Sostituto
9 CBL/SAT	SHIFT + BLUETOOTH 9		
0/11 CBL/SAT	SHIFT + HDMI - SAT 0		

Shift + 9

Shift + 0

Originale	Sostituto	Originale	Sostituto
Power CD	Power	Play CD	Play / Slow
CD	Smart / List	>> CD	>> / Tune+
CH/Disc+ CD	CH+ / Page+	Pause CD	Pause / Step / Freeze
Vol + Receiver	Vol +	Stop CD	Stop / Hold
CH/Disc- CD	CH- / Page-	Search CD	Red / Netflix / Search
Vol - Receiver	Vol -	Repeat CD	Green / APP / Repeat
Up CD	Up	Random CD	Blue / Prime Video / Random
Left CD	Left	Play Mode CD	Yellow / YouTube / Repeat
Enter CD	OK	1 CD	1
Right CD	Right	2 CD	2
Setup CD	Setup / OPT /	3 CD	3
Down CD	Down	4 CD	4
Return CD	Back / Return	5 CD	5
Audio CD	Audio / Lang I/II	6 CD	6
I<< CD	I<< / Preset-	7 CD	7
>>I CD	>>I / Preset+	8 CD	8
<< CD	<< / Tune-	9 CD	9

Originale	Sostituto	Originale	Sostituto
+10/--/--10/D.Tu Dimmer CD	Guide / EPG / -/--		
0/11 CD	0		
CLR/Sleep/12	Fav / Marker / PC		

Originale		Sostituto		Originale		Sostituto	
ON/STANDBY	Power Receiver Zone 2		Power		>> Zone 2	TUNE+	>> / Tune+
CH DISC	CH Disc/Album+ Zone 2	CH PAGE	CH+ / Page+		Pause Zone 2	STEP-FREEZE	Pause / Step / Freeze
VOL	Vol + Zone 2	VOL	Vol +		Stop Zone 2	HOLD	Stop / Hold
ALBUM	CH Disc/Album- Zone 2	CH PAGE	CH- / Page-	MOVIE/TV SEARCH	Movie Tv Zone	NETFLIX SEARCH	Red / Netflix / Search
VOL	Vol - Zone 2	VOL	Vol -	MUSIC REPEAT	Music Zone 2	APP REPEAT	Green / APP / Repeat
	Up Zone 2		Up	GAME RANDOM	Game Zone 2	YouTube REPEAT A-B	Yellow / YouTube / Repeat
PLAYLIST /CATEGORY	Left Zone 2		Left	STEREO PLAY MODE	Stereo Zone 2	Prime Video RANDOM	Blue / Prime Video / Random
ENTER	Enter Zone 2	OK	OK	1	1 Zone 2	TV 1	1
PLAYLIST /CATEGORY	Right Zone 2		Right	2	2 Zone 2	DVD 2	2
SETUP	Setup Zone 2	OPT-TOOLS SETUP	Setup / OPT /	3	3 Zone 2	CD-STB 3	3
	Down Zone 2		Down	4	4 Zone 2	VIDEO 4	4
RETURN	Return Zone 2	RETURN BACK	Back / Return	5	5 Zone 2	TAPE 5	5
AUDIO	Audio Zone 2	LANG I/II AUDIO	Audio / Lang I/II	6	6 Zone 2	TUNER 6	6
	I<< Zone 2	PRESET-	I<< / Preset-	7	7 Zone 2	AUX-HDD 7	7
	>>I Zone 2	PRESET+	>>I / Preset+	8	8 Zone 2	USB 8	8
	<< Zone 2	TUNE-	<< / Tune-	9	9 Zone 2	BLUETOOTH 9	9
	Play Zone 2	SLOW	Play / Slow	+10	+10/--/--10/D.Tuning Dimmer Zone 2	-/-- GUIDE EPG	Guide / EPG / -/--

Originale	Sostituto	Originale	Sostituto
0/11 Zone 2	0		
CLR/Sleep/12	Fav / Marker / PC		