# Mandis shop

Yamaha VR09400

| Originale | | Sostituto | |
|---|---|---|---|
| POWER | Power | | Power |
| SLEEP | Sleep | TIMER SLEEP | Sleep / Timer |
| PLAY/CUT | Play/Cut | MEDIA DISPLAY | Display / Media |
| PHONO | Phono | DVD 2 | 2 |
| SKIP | I<< CD | PRESET- | I<< / Preset- |
| SKIP | >>I CD | PRESET+ | >>I / Preset+ |
| PLAY | Play CD | SLOW | Play / Slow |
| CD | CD | CD-STB 3 | 3 |
| SEARCH | << CD | TUNE- | << / Tune- |
| SEARCH | >> CD | TUNE+ | >> / Tune+ |
| PAUSE/STOP | Pause CD | STEP-FREEZE | Pause / Step / Freeze |
| PAUSE/STOP | Stop CD | HOLD | Stop / Hold |
| DISC SKIP | Disc Skip CD | SURROUND | Eject / Surround |
| PRESET- | Preset- Tuner | SHIFT + PRESET- | Shift + I<< / Preset- |
| PRESET- | Preset- Tuner | CH PAGE - | CH- / Page- |
| PRESET+ | Preset+ Tuner | SHIFT + PRESET+ | Shift + >>I / Preset+ |
| PRESET+ | Preset+ Tuner | CH PAGE + | CH+ / Page+ |

| Originale | | Sostituto | |
|---|---|---|---|
| A/B/C/D/E | A/B/C/D/E Tuner | LIST SMART | Smart / List |
| TUNER | Tuner | TUNER 6 | 6 |
| DIR A | Dir A Tape | | Left |
| DECK A/B | Deck A/B Tape | OK | OK |
| DIR B | Dir B Tape | | Right |
| TAPE 1 | Tape 1 | TAPE 5 | 5 |
| << | << Tape | SHIFT + TUNE- | Shift + << / |
| PLAY | Play Tape | SHIFT + SLOW | Shift + Play / |
| >> | >> Tape | SHIFT + TUNE+ | Shift + >> / |
| TAPE 2 | Tape 2 | VIDEO 4 | 4 |
| REC/PAUSE | Rec/Pause Tape | SHIFT + STEP-FREEZE | Shift + Pause / Step / |
| STOP | Stop Tape | SHIFT + HOLD | Shift + Stop / |
| REC MUTE | Rec Mute | DIMMER MUTE | Mute / Dimmer |
| AUX | AUX | AUX-HDD 7 | 7 |
| - | Vol - | VOL - | Vol - |
| + | Vol + | VOL + | Vol + |

https://tutti-i-telecomandi.it/it/Yamaha/1655863/telecomando-sostituzione-per-Yamaha-VR09400.htm