Originale	Sostituto
Power	Power
PIC Mode	V-FOR
PIC Size	WIDE
Sleep	SHIFT + Shift + Power
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
--/+10/100	-/-- / EPG
Input	SRC
FAV Browser/Top Menu	MEDIA

Originale	Sostituto
Recall	BACK
Vol +	VOL +
Vol -	VOL -
Mute	MUTE
CH+	CH +
CH-	CH -
CH RTN/DVD	P/C / FAV
Guide/Set Up	SHIFT + EPG Shift + -/-- / EPG
Info	INFO
Up	UP
Down	DOWN
Right/Next [CB	RIGHT
Left/Back [CB]	LEFT
Enter	OK
Menu	MENU
Exit/DVD Clear	EXIT
Pause/Step	Pause

Originale	Sostituto	Originale	Sostituto
Play	Play		
Stop	Stop		
I <<	First		
<<	Rewind		
>>	Fast Forward		
>>I	Last		
Rec	Rec		
Eject	Yellow (C)		
◁ Slow	Red (A)		
Slow I >	Green (B)		
Tv/VCR/Search	TV/R		
Camera/Angle	OPT+		
[...]/Subtitl	Subt.		
O))/Audio	Audio		

Originale		Sostituto	
POWER	Power		Power
SLEEP	Sleep	SHIFT +	Shift + Power
PIC SIZE	PIC Size	WIDE	WIDE
PIC MODE	PIC Mode	V-FOR	V-FOR
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
INPUT	Input	SRC	SRC
+10 100	-/+10/100	EPG	-/-- / EPG
MUTE	Mute		MUTE

Originale		Sostituto	
+ VOL	Vol +	+ VOL	VOL +
VOL −	Vol -	VOL −	VOL -
CH ▲	CH+	+ CH	CH +
CH ▼	CH-	CH −	CH -
RECALL	Recall	BACK	BACK
INFO	Info	INFO	INFO
SET UP GUIDE	Guide/Set Up	SHIFT + EPG	Shift + -/-- / EPG
MENU	Menu	MENU	MENU
DVD CLEAR EXIT	Exit/DVD Clear	EXIT	EXIT
ENTER	Enter	OK	OK
	Up		UP
	Down		DOWN
NEXT	Right/Next [CB]		RIGHT
BACK	Left/Back [CB]		LEFT

Originale		Sostituto	
POWER	Power		Power
PIC SIZE	PIC Size	WIDE	WIDE
PIC MODE	PIC Mode	V-FOR	V-FOR
SLEEP	Sleep	SHIFT +	Shift + Power
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
+10 100	-/+10/100	EPG	-/-- / EPG
INPUT	Input	SRC	SRC
MUTE	Mute		MUTE

Originale		Sostituto	
+ VOL	Vol +	+ VOL	VOL +
VOL –	Vol -	VOL –	VOL -
CH	CH+	+ CH	CH +
CH	CH-	CH –	CH -
RECALL	Recall	BACK	BACK
PAUSE/STEP	Pause/Step		Pause
PLAY	Play		Play
STOP	Stop		Stop
REW	<<		Rewind
FF	>>		Fast Forward
TV/VCR SEARCH	Tv/VCR/Search	TV/R	TV/R

Originale		Sostituto	
POWER	Power		Power
PIC SIZE	PIC Size	WIDE	WIDE
PIC MODE	PIC Mode	V-FOR	V-FOR
SLEEP	Sleep	SHIFT +	Shift + Power
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
+10 100	--/+10/100	EPG	-/-- / EPG
INPUT	Input	SRC	SRC
TOP MENU FAV BROWSER	FAV Browser/Top Menu	MEDIA	MEDIA

Originale		Sostituto	
MUTE	Mute		MUTE
+ VOL	Vol +	+ VOL	VOL +
VOL –	Vol -	VOL –	VOL -
SET UP GUIDE	Guide/Set Up	SHIFT + EPG	Shift + -/-- / EPG
MENU	Menu	MENU	MENU
DVD CLEAR EXIT	Exit/DVD Clear	EXIT	EXIT
INFO	Info	INFO	INFO
RECALL	Recall	BACK	BACK
DVD RTN CH RTN	CH RTN/DVD	FAV P/C	P/C / FAV
ENTER	Enter	OK	OK
	Up		UP
	Down		DOWN
NEXT	Right/Next [CB]		RIGHT
BACK	Left/Back [CB]		LEFT
PAUSE/STEP	Pause/Step		Pause
PLAY	Play		Play
STOP	Stop		Stop

Originale		Sostituto		Originale	Sostituto
SKIP	I <<		First		
REW	<<		Rewind		
FF	>>		Fast Forward		
SKIP	>>I		Last		
EJECT	Eject	C	Yellow (C)		
TV/VCR SEARCH	Tv/VCR/Search	TV/R	TV/R		
ANGLE	Camera/Angle	OPT+	OPT+		
SUB TITLE	[...]/Subtitl		Subt.		
AUDIO	O))/Audio		Audio		