Mandis shop

# Philips 996580000536

| Originale | | Sostituto | |
|---|---|---|---|
| | Power | | Power |
| COAX | Coax | A | Red |
| | Play | PLAY MODE | Play |
| | Pause | | Pause |
| OPTICAL | Optical | B | Green |
| AUX | AUX | C | Yellow |
| USB | USB | D | Blue |
| | I< | | I<< |
| | >I | | >>I |
| | Vol+ | VOL + | Vol + |
| | Vol- | VOL − | Vol - |
| | Mute | MUTE | Mute |
| TREBLE + | Treble+ | CH + | Ch + |
| TREBLE − | Treble- | CH − | Ch - |
| BASS + | Bass+ | | Up |
| BASS − | Bass- | | Down |
| AUDIO SYNC − | Audio Sync - | | Left |

| Originale | | Sostituto | |
|---|---|---|---|
| AUDIO SYNC + | Audio Sync + | | Right |
| OFF SURROUND | Surround Off | PICTURE FORMAT | Format |
| SURROUND ON | Surround On | ECO 3D | 3D |
| SOUND | Sound | SOUND DUAL | Dual |
| DIM | DIM | APP MEDIA | Media |
| NIGHT | Night | HOME SMART | Smart |
| | Bluetooth | - / -- GUIDE | Guide |
| HDMI ARC | HDMI ARC | FAV PRE-CH | Pre Ch |

https://tutti-i-telecomandi.it/it/Philips/1055658-66032-telecomando-di-sostituzione-per-Philips-996580000536.html