Mandis shop

# Philips 996510067904

| Originale | | Sostituto | |
|---|---|---|---|
| | Power | | Power |
| HDMI ARC | HDMI ARC | 1 | 1 |
| Bluetooth | Bluetooth | 3 | 3 |
| AUX/ AUDIO IN | AUX/Audio In | 4 | 4 |
| USB | USB | 2 | 2 |
| COAX/ OPTICAL | Coax/Optical | 5 | 5 |
| | I< | | I<< |
| | Play | PLAY MODE | Play |
| | Pause | | Pause |
| | >I | | >>I |
| + BASS | Bass+ | | Up |
| BASS − | Bass- | | Down |
| + VOLUME | Vol+ | + VOL | Vol + |
| VOLUME − | Vol- | VOL − | Vol - |
| + TREBLE | Treble+ | + CH | Ch + |
| TREBLE − | Treble- | CH − | Ch - |
| | Mute | MUTE | Mute |

| Originale | | Sostituto | |
|---|---|---|---|
| SOUND | Sound | SOUND DUAL | Dual |
| SURR | Surr | AD SUBT | Subt |
| DIM | DIM | HOME SMART | Smart |
| NIGHT MODE | Night Mode | APP MEDIA | Media |

https://tutti-i-telecomandi.it/it/Philips/1055662-78248-telecomando-di-sostituzione-per-Philips-Soundstage-996510067904.html