Originale		Sostituto	
	Power		Power
	Mute		Mute
	Sleep/Timer		Smart
	Clock/Display		3D
	RDS/Info		Info
	Menu		Menu
	Prog		Sleep
	DBB		Exit
	Play/Pause		Play
	Stop		Stop
	Vol+		Vol +
	Vol-		Vol -
	Repeat		Text
	Shuffle		Ch -
	OK		Ok
	Up		Up
	Down		Down

Originale		Sostituto	
	>>I		>>I
	>>I		Right
	I<<		I<<
	I<<		Left

Originale		Sostituto	
MUTE	Mute	MUTE	Mute
▶II	Play/Pause	PLAY MODE ▶	Play
⏻	Power	⏻	Power
OK	OK	OK	Ok
▲	Up	▲	Up
▼	Down	▼	Down
⏭	>>I	⏭	>>I
⏭	>>I	▶	Right
⏮	I<<	⏮	I<<
⏮	I<<	◀	Left
PROG	Prog	PROG SLEEP	Sleep
■	Stop	■	Stop
+ VOL	Vol+	+ VOL	Vol +
VOL –	Vol-	VOL –	Vol -
REPEAT	Repeat	REPEAT TEXT	Text
SHUFFLE	Shuffle	CH –	Ch -
SCAN	Scan	RETURN BACK	Back

Originale		Sostituto	
TIMER SLEEP	Sleep/Timer	HOME SMART	Smart
DISPLAY CLOCK	Clock/Display	ECO 3D	3D
INFO. RDS	RDS/Info	DISPLAY INFO	Info
MENU	Menu	TOP MENU MENU	Menu
DBB	DBB	CLEAR EXIT	Exit

Originale		Sostituto	
	Power		Power
	Mute		Mute
	Sleep/Timer		Smart
	Clock/Display		3D
	RDS/Info		Info
	Menu		Menu
	DBB		Exit
	Scan		Back
	Prog		Sleep
	Stop		Stop
	Vol+		Vol +
	Vol-		Vol -
	Repeat		Text
	OK		Ok
	Down		Down
	Up		Up
	>>I		>>I

Originale		Sostituto	
	>>I		Right
	I<<		I<<
	I<<		Left

Originale		Sostituto	
	Power		Power
	Mute		Mute
	Sleep/Timer		Smart
	Clock/Display		3D
	RDS/Info		Info
	DBB		Exit
	Stop		Stop
	Vol+		Vol +
	Vol-		Vol -

Originale	Sostituto