Mandis shop

Sony RM-SC50

Originale		Sostituto	
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
I / ⏻	Power	⏻	Power
DISPLAY	Display	MEDIA DISPLAY	Display / Media
SELECT	Clock Timer	TOP MENU D.MENU	D.Menu / Top
SET	Clock Timer Set	HOME MENU	Menu / Home
TUNER MEMORY	Tuner Memory	◀	Left
PLAY MODE/ TUNING MODE	Play Mode/Tuning Mode	▶	Right
REPEAT/ FM MODE	Repeat/FM	APP REPEAT	Green / APP / Repeat
REPEAT/ FM MODE	Repeat/FM	▼	Down
TAPE	Tape	TAPE 5	5
CD	CD	CD - STB 3	3
TUNER BAND	Band/Tuner	▲	Up
TUNER BAND	Band/Tuner	TUNER 6	6
FUNCTION	Function	LIST SMART	Smart / List
– ⏮	I<<\/-	PRESET- ⏮	I<< / Preset-
+ ⏭	>>I/+	PRESET+ ⏭	>>I / Preset+
◀◀	<<	TUNE- ◀◀	<< / Tune-

Originale		Sostituto	
▶▶	>>	TUNE+ ▶▶	>> / Tune+
▶	Play	SLOW ▶	Play / Slow
⏸	Pause	STEP - FREEZE ⏸	Pause / Step / Freeze
■	Stop	HOLD ■	Stop / Hold
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear
VOLUME +	Vol+	+ VOL	Vol+
ENTER	Enter	OK	OK
EQ	EQ	EQ SUBTITLE	Subtitle / EQ
VOLUME –	Vol-	VOL –	Vol-
DISC SKIP	Disc Skip	SURROUND ⏏	Eject / Surround
🗀 –	Folder-	CH PAGE –	CH- / Page-
🗀 +	Folder+	+ CH PAGE	CH+ / Page+

https://tutti-i-telecomandi.it/it/Sony/1055954-6103-telecomando-di-sostituzione-per-Sony-RM-SC-50-A1108433B.html