Originale		Sostituto	
POWER	Power		Power
ENTER	Enter	OK	Ok
	Up		Up
	Down		Down
	Right		Right
	Left		Left
VOLUME	Vol+	+ VOL	Vol +
	Vol-	VOL −	Vol -
MUTE	Mute	MUTE	Mute
CH / PAGE	CH/Page+	+ CH	Ch +
	CH/Page-	CH −	Ch -
BACK	Back	RETURN BACK	Back
SETUP	Setup	TOP MENU MENU	Menu
OPTION	Option	SETTINGS OPT	Options
INFO	Info	DISPLAY INFO	Info
SLEEP	Sleep	PROG SLEEP	Sleep
HOME	Home	HOME SMART	Smart

Originale		Sostituto	
	Play	PLAY MODE	Play
	Pause		Pause
	Stop		Stop
	Tune+/>>I		>>I
	I<</Tune-		I<<
	<<		<<
	>>		>>
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0

Originale		Sostituto	
MOVIE	Red/Movie	A	Red
MUSIC	Green/Music	B	Green
GAME	Blue/Game	D	Blue
PURE	Yellow/Pure	C	Yellow
1	Favorite Station 1	E-MANUAL D.MENU	D. Menu
2	Favorite Station 2	REPEAT TEXT	Text
3	Favorite Station 3	ZOOM ⏏	Eject
4	Favorite Station 4	TIMER AV	AV
InstaPrevue	InstaPreuve	ECO 3D	3D
CBL/SAT	CBL/SAT	SHIFT + 1	Shift + 1
DVD	DVD	SHIFT + 2	Shift + 2
Blu-ray	Blu-ray	SHIFT + 3	Shift + 3
AUX1	AUX1	SHIFT + 4	Shift + 4
M-XPort	M-XPort	SHIFT + 5	Shift + 5
TUNER	Tuner	SHIFT + 6	Shift + 6
GAME	Game	SHIFT + 7	Shift + 7
AUX2	AUX2	SHIFT + 8	Shift + 8

Originale		Sostituto	
PHONO	Phono	SHIFT + 9	Shift + 9
iPod/USB	iPod/USB	SHIFT + -/-- GUIDE	Shift + Guide
MEDIA PLAYER	Media Player	APP MEDIA	Media
CD	CD	FAV PRE-CH	Pre Ch
NETWORK	Network	-/-- GUIDE	Guide
INTERNET RADIO	Internet Radio	SEARCH TV/R	TV/R
TV AUDIO	Tv Audio	SOUND DUAL	Dual

Originale		Sostituto	
POWER	Power	POWER	Power
CH / PAGE ▲	CH/Page+	+ CH	Ch +
▼	CH/Page-	CH −	Ch -
SLEEP	Sleep	PROG SLEEP	Sleep
VOLUME ▲	Vol+	+ VOL	Vol +
▼	Vol-	VOL −	Vol -
MUTE	Mute	MUTE	Mute
BACK	Back	RETURN BACK	Back
❚❚	Pause	❚❚	Pause
▶	Play	PLAY MODE ▶	Play
■	Stop	■	Stop
HOME	Home	HOME SMART	Smart
I<<</Tune-	I<<</Tune-	⏮	I<<
>>I/Tune+	>>I/Tune+	⏭	>>I
<<	<<	«	<<
>>	>>	»	>>
1	1	1	1

Originale		Sostituto	
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
ENTER	Enter	OK	Ok
▲	Up	▲	Up
▼	Down	▼	Down
▶	Right	▶	Right
◀	Left	◀	Left
1	Favorite Station 1	E-MANUAL D.MENU	D. Menu
2	Favorite Station 2	REPEAT TEXT	Text
3	Favorite Station 3	ZOOM ⏏	Eject

Originale	Sostituto	Originale	Sostituto
4 Favorite Station 4	TIMER AV		
CBL/SAT	SHIFT + 1		
DVD	SHIFT + 2		
Blu-ray	SHIFT + 3		
AUX1	SHIFT + 4		
M-XPort	SHIFT + 5		
TUNER	SHIFT + 6		
GAME	SHIFT + 7		
AUX2	SHIFT + 8		
PHONO	SHIFT + 9		
iPod/USB	SHIFT + GUIDE		
MEDIA PLAYER	APP MEDIA		
CD	FAV PRE-CH		
NETWORK	GUIDE		
INTERNET RADIO	SEARCH TV/R		
TV AUDIO	SOUND DUAL		

Originale		Sostituto	
POWER	Power		Power
TV AUDIO	Tv Audio	SOUND DUAL	Dual
SLEEP	Sleep	PROG SLEEP	Sleep
MUTE	Mute	MUTE	Mute
BACK	Back	RETURN BACK	Back
CH / PAGE	CH/Page+	+ CH	Ch +
	CH/Page-	CH –	Ch -
VOLUME	Vol+	+ VOL	Vol +
	Vol-	VOL –	Vol -
	Up		Up
	Down		Down
	Right		Right
	Left		Left
ENTER	Enter	OK	Ok
HOME	Home	HOME SMART	Smart
	Stop		Stop
	Pause		Pause

Originale		Sostituto	
	Play	PLAY MODE	Play
TU	I<<</Tune-		I<<
NE +	>>I/Tune+		>>I
	<<		<<
	>>		>>
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
1	Favorite Station 1	E-MANUAL D.MENU	D. Menu
2	Favorite Station 2	REPEAT TEXT	Text

Originale	Sostituto	Originale	Sostituto
3 Favorite Station 3	ZOOM Eject		
4 Favorite Station 4	TIMER AV AV		
CBL/SAT CBL/SAT	SHIFT + 1 Shift + 1		
DVD DVD	SHIFT + 2 Shift + 2		
Blu-ray Blu-ray	SHIFT + 3 Shift + 3		
AUX1 AUX1	SHIFT + 4 Shift + 4		
M-XPort M-XPort	SHIFT + 5 Shift + 5		
TUNER Tuner	SHIFT + 6 Shift + 6		
GAME Game	SHIFT + 7 Shift + 7		
AUX2 AUX2	SHIFT + 8 Shift + 8		
PHONO Phono	SHIFT + 9 Shift + 9		
iPod/USB iPod/USb	SHIFT + -/-- GUIDE Shift + Guide		
CD CD	FAV PRE-CH Pre Ch		
MEDIA PLAYER Media Player	APP MEDIA Media		
NETWORK Network	-/-- GUIDE Guide		
INTERNET RADIO Internet Radio	SEARCH TV/R TV/R		