Originale	Sostituto	Originale	Sostituto
Open/Close	Eject / Surround	P.Scan	Blue / Prime Video / Random
Power	Power	Menu	Menu / Home
VCR	Shift + 4	Setup	Setup / OPT /
DVD	Shift + 2	Up	Up
TV / VCR	TV/Radio /	PR+	CH+ / Page+
TV / View	Smart / List	PR-	CH- / Page-
2	2	Down	Down
4	4	Left	Left
1 / Tracking -	1	Right	Right
5	5	Enter	OK
3 / Tracking +	3	Edit	Fav / Marker / PC
6	6	Display	Display / Media
7	7	I<<	I<< / Preset-
8	8	>>I	>>I / Preset+
9	9	Pause	Pause / Step / Freeze
Clear	Exit / Cancel / Clear	Play	Play / Slow
0	0	<<	<< / Tune-

Originale	Sostituto	Originale	Sostituto
FF >>	TUNE+ >> / Tune+		
STOP Stop	HOLD Stop / Hold		
Rec	REC MODE Rec / Rec Mode		
INPUT Input	RDS AV INPUT AV / Input / RDS		
SUBTITLE Subtitle	EQ SUBTITLE Subtitle / EQ		
SLOW− <I / Slow -	VOL − Vol-		
SLOW+ Slow + / I>	+ VOL Vol+		
COPY Copy	-/-- GUIDE EPG Guide / EPG / -/--		
ANGLE Angle	ANGLE INFO Info / Angle		
REC SPEED Rec Speed	SHIFT + REC MODE Shift + Rec / Rec Mode		
ZOOM Zoom	SIZE ZOOM Zoom / Size		
REPEAT Repeat	APP REPEAT Green / APP / Repeat		
A-B A-B	YouTube REPEAT A-B Yellow / YouTube / Repeat		
SEARCH Search	NETFLIX SEARCH Red / Netflix / Search		
AUDIO Audio	LANG I/II AUDIO Audio / Lang I/II		
TITLE Title	TITLE SOUND Sound / Title		
TIMER Timer	TIMER SLEEP Sleep / Timer		

Originale		Sostituto	
OPEN/CLOSE	Open/Close	SURROUND	Eject / Surround
POWER	Power		Power
VCR	VCR	SHIFT + VIDEO 4	Shift + 4
DVD	DVD	SHIFT + DVD 2	Shift + 2
TV/VCR	TV / VCR	PROGRAM TV/RADIO	TV/Radio /
TV VIEW	TV / View	LIST SMART	Smart / List
2	2	DVD 2	2
4	4	VIDEO 4	4
1	1 / Tracking -	TV 1	1
5	5	TAPE 5	5
3	3 / Tracking +	CD-STB 3	3
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear
0	0	HDMI-SAT 0	0

Originale		Sostituto	
P.SCAN	P.Scan	Prime Video RANDOM	Blue / Prime Video / Random
MENU	Menu	HOME MENU	Menu / Home
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
	Up		Up
	PR+	CH PAGE +	CH+ / Page+
	PR-	CH PAGE −	CH- / Page-
	Down		Down
	Left		Left
	Right		Right
ENTER	Enter	OK	OK
EDIT	Edit	PC FAV MARKER	Fav / Marker / PC
DISPLAY	Display	MEDIA DISPLAY	Display / Media
PREV	I<<	PRESET−	I<< / Preset-
NEXT	>>I	PRESET+	>>I / Preset+
▶/II	Pause	STEP-FREEZE II	Pause / Step / Freeze
▶/II	Play	SLOW ▶	Play / Slow
REW	<<	TUNE−	<< / Tune-

Originale	Sostituto	Originale	Sostituto
FF >>	TUNE+ >> / Tune+		
STOP Stop	HOLD Stop / Hold		
Rec	REC MODE Rec / Rec Mode		
INPUT Input	RDS AV INPUT AV / Input / RDS		
SUBTITLE Subtitle	EQ SUBTITLE Subtitle / EQ		
SLOW− <I / Slow -	VOL − Vol-		
SLOW+ Slow + / I>	+ VOL Vol+		
COPY Copy	-/-- GUIDE EPG Guide / EPG / -/--		
ANGLE Angle	ANGLE INFO Info / Angle		
REC SPEED Rec Speed	SHIFT + REC MODE Shift + Rec / Rec Mode		
ZOOM Zoom	SIZE ZOOM Zoom / Size		
REPEAT Repeat	APP REPEAT Green / APP / Repeat		
A-B A-B	YouTube REPEAT A-B Yellow / YouTube / Repeat		
SEARCH Search	NETFLIX SEARCH Red / Netflix / Search		
AUDIO Audio	LANG I/II AUDIO Audio / Lang I/II		
TITLE Title	TITLE SOUND Sound / Title		
TIMER Timer	TIMER SLEEP Sleep / Timer		