| Originale | | Sostituto | |
|---|---|---|---|
| | Power Tv | | Power |
| | Av Tv | TIMER AV | AV |
| | Menu Tv | TOP MENU MENU | Menu |
| | Up Tv | | Up |
| | Down Tv | | Down |
| | Left Tv | | Left |
| | Right Tv | | Right |
| OK | Ok Tv | OK | Ok |
| INFO | Info Tv | DISPLAY INFO | Info |
| EXIT | Exit Tv | CLEAR EXIT | Exit |
| | Red Tv | A | Red |
| | Green Tv | B | Green |
| | Yellow Tv | C | Yellow |
| | Blue Tv | D | Blue |
| + VOL | Vol + Tv | + VOL | Vol + |
| VOL − | Vol - Tv | VOL − | Vol - |
| | Mute Tv | MUTE | Mute |

| Originale | | Sostituto | |
|---|---|---|---|
| P-P | Back Tv | RETURN BACK | Back |
| + CH | Ch+ Tv | + CH | Ch + |
| CH − | Ch- Tv | CH − | Ch - |
| ▼P | ▼P[ ≡] Tv | | I << |
| ▲P | ▲P[ ] Tv | | >>I |
| | << Tv | | << |
| | >> Tv | | >> |
| | Stop Tv | | Stop |
| | Play Tv | PLAY MODE | Play |
| 1 | 1 Tv | 1 | 1 |
| 2 | 2 Tv | 2 | 2 |
| 3 | 3 Tv | 3 | 3 |
| 4 | 4 Tv | 4 | 4 |
| 5 | 5 Tv | 5 | 5 |
| 6 | 6 Tv | 6 | 6 |
| 7 | 7 Tv | 7 | 7 |
| 8 | 8 Tv | 8 | 8 |

| Originale | Sostituto |
|---|---|
| 9 Tv | 9 |
| 0 Tv | 0 |
| Text Tv | Text |
| #Help Tv | Pre Ch |
| ▼P [ ≡] Tv2 | Shift + I << |
| ▲P [ ] Tv2 | Shift + >>I |
| Rec Tv2 | Shift + Rec |
| Play Tv2 | Shift + Play |
| Av Tv2 | Shift + AV |
| << Tv2 | Shift + << |
| >> Tv2 | Shift + >> |
| Power Tv2 | Shift + Power |
| Guide Tv2 | Shift + Guide |
| Menu Tv2 | Shift + Menu |
| Up Tv2 | Shift + Up |
| Left Tv2 | Shift + Left |
| Right Tv2 | Shift + Right |

| Originale | Sostituto |
|---|---|
| Down Tv2 | Shift + Down |
| Ok Tv2 | Shift + Ok |
| Info Tv2 | Shift + Info |
| Green Tv2 | Shift + Green |
| Red Tv2 | Shift + Red |
| Exit Tv2 | Shift + Exit |
| Yellow Tv2 | Shift + Yellow |
| Blue Tv2 | Shift + Blue |
| Back Tv2 | Shift + Back |
| Ch+ Tv2 | Shift + Ch + |
| Ch- Tv2 | Shift + Ch - |
| Stop Tv2 | Shift + Stop |
| Pause Tv2 | Shift + Pause |
| 1 Tv2 | Shift + 1 |
| 2 Tv2 | Shift + 2 |
| 3 Tv2 | Shift + 3 |
| 4 Tv2 | Shift + 4 |

| Originale | Sostituto | Originale | Sostituto |
|---|---|---|---|
| 5 5 Tv2 | SHIFT + 5 Shift + 5 | | |
| 6 6 Tv2 | SHIFT + 6 Shift + 6 | | |
| 7 7 Tv2 | SHIFT + 7 Shift + 7 | | |
| 8 8 Tv2 | SHIFT + 8 Shift + 8 | | |
| 9 9 Tv2 | SHIFT + 9 Shift + 9 | | |
| 0 0 Tv2 | SHIFT + 0 Shift + 0 | | |
| * TXT Text Tv2 | SHIFT + REPEAT TEXT Shift + Text | | |
| # HELP #Help Tv2 | SHIFT + FAV PRE-CH Shift + Pre Ch | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

| Originale | Sostituto |
|---|---|
| Power DVD | Power |
| AV DVD/DVR | AV |
| Guide DVD/DVR | Guide |
| Menu DVD/DVR | Menu |
| Info DVD/DVR | Info |
| Exit DVD/DVR | Exit |
| Up DVD/DVR | Up |
| Down DVD/DVR | Down |
| Left DVD/DVR | Left |
| Right DVD/DVR | Right |
| Ok DVD/DVR | Ok |
| Red DVD/DVR | Red |
| Green DVD/DVR | Green |
| Yellow | Yellow |
| Blue DVD/DVR | Blue |
| Vol + DVD/DVR | Vol + |
| Vol - DVD/DVR | Vol - |

| Originale | Sostituto |
|---|---|
| Mute DVD/DVR | Mute |
| Back DVD/DVR | Back |
| Ch+ DVD/DVR | Ch + |
| ▼P[ ≡] DVD/DVR | I << |
| Ch- DVD/DVR | Ch - |
| ▲P[ ] DVD/DVR | >>I |
| << DVD/DVR | << |
| >> DVD/DVR | >> |
| Play DVD/DVR | Play |
| Pause DVD/DVR | Pause |
| Stop DVD/DVR | Stop |
| Rec DVD/DVR | Rec |
| 1 DVD/DVR | 1 |
| 2 DVD/DVR | 2 |
| 3 DVD/DVR | 3 |
| 4 DVD/DVR | 4 |
| 5 DVD/DVR | 5 |

| Originale | Sostituto | Originale | Sostituto |
|---|---|---|---|
| 6 DVD/ DVR | 6 | | |
| 7 DVD/ DVR | 7 | | |
| 8 DVD/ DVR | 8 | | |
| 9 DVD/ DVR | 9 | | |
| 0 DVD/ DVR | 0 | | |
| Text DVD/ DVR | Text | | |
| #Help DVD/ DVR | Pre Ch | | |
| Power DVR | SHIFT + Power | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

| Originale | Sostituto |
|---|---|
| Power | Power |
| Menu | Menu |
| Guide | Guide |
| AV SAT/CABLE | AV |
| Up SAT/CABLE | Up |
| Down | Down |
| Left SAT/CABLE | Left |
| Right | Right |
| Ok SAT/CABLE | Ok |
| Info SAT/CABLE | Info |
| Exit SAT/CABLE | Exit |
| Red SAT/CABLE | Red |
| Green | Green |
| Yellow SAT/CABLE | Yellow |
| Blue SAT/CABLE | Blue |
| Vol + | Vol + |
| Vol - SAT/CABLE | Vol - |

| Originale | Sostituto |
|---|---|
| Mute | Mute |
| Back | Back |
| Ch+ SAT/CABLE | Ch + |
| Ch- SAT/CABLE | Ch - |
| << SAT/CABLE | << |
| >> SAT/CABLE | >> |
| Stop SAT/CABLE | Stop |
| Rec SAT/CABLE | Rec |
| Play SAT/CABLE | Play |
| Pause | Pause |
| 1 SAT/CABLE | 1 |
| 2 SAT/CABLE | 2 |
| 3 SAT/CABLE | 3 |
| 4 SAT/CABLE | 4 |
| 5 SAT/CABLE | 5 |
| 6 SAT/CABLE | 6 |
| 7 SAT/CABLE | 7 |

| Originale | | Sostituto | |
|---|---|---|---|
| 8 | 8 SAT/ CABLE | 8 | 8 |
| 9 | 9 SAT/ CABLE | 9 | 9 |
| 0 | 0 SAT/ CABLE | 0 | 0 |
| # HELP | #Help | FAV PRE-CH | Pre Ch |
| * TXT | Text SAT/ CABLE | REPEAT TEXT | Text |

| Originale | Sostituto |
|---|---|
| | |

| Originale | Sostituto |
|---|---|
| Power DVBT | Power |
| Guide DVBT | Guide |
| Menu DVBT | Menu |
| Up DVBT | Up |
| Down DVBT | Down |
| Left DVBT | Left |
| Right DVBT | Right |
| Ok DVBT | Ok |
| Info DVBT | Info |
| Red DVBT | Red |
| Green DVBT | Green |
| Yellow DVBT | Yellow |
| Blue DVBT | Blue |
| Vol + DVBT | Vol + |
| Vol - DVBT | Vol - |
| Mute DVBT | Mute |
| Back DVBT | Back |

| Originale | Sostituto |
|---|---|
| Ch+ DVBT | Ch + |
| Ch- DVBT | Ch - |
| Pause DVBT | Pause |
| 1 DVBT | 1 |
| 2 DVBT | 2 |
| 3 DVBT | 3 |
| 4 DVBT | 4 |
| 5 DVBT | 5 |
| 6 DVBT | 6 |
| 7 DVBT | 7 |
| 8 DVBT | 8 |
| 9 DVBT | 9 |
| 0 DVBT | 0 |
| Power VCR | Shift + Power |
| Av VCR | AV |
| << VCR | << |
| Stop VCR | Stop |

| Originale | Sostituto |
|---|---|
| >> VCR | >> |
| Play VCR | PLAY MODE Play |
| Rec VCR | REC MODE Rec |
| Pause VCR | SHIFT + Shift + Pause |
| Guide VCR | SHIFT + GUIDE Shift + Guide |
| Menu VCR | SHIFT + TOP MENU MENU Shift + Menu |
| Up VCR | SHIFT + Shift + Up |
| Down VCR | SHIFT + Shift + Down |
| Left VCR | SHIFT + Shift + Left |
| Right VCR | SHIFT + Shift + Right |
| Ok VCR | SHIFT + OK Shift + Ok |
| Info VCR | SHIFT + DISPLAY INFO Shift + Info |
| Exit VCR | CLEAR EXIT Exit |
| Red VCR | SHIFT + A Shift + Red |
| Green VCR | SHIFT + B Shift + Green |
| Yellow VCR | SHIFT + C Shift + Yellow |
| Blue VCR | SHIFT + D Shift + Blue |

| Originale | Sostituto |
|---|---|
| P<P Back VCR | SHIFT + RETURN BACK Shift + Back |
| CH + Ch+ VCR | SHIFT + CH + Shift + Ch + |
| CH − Ch- VCR | SHIFT + CH − Shift + Ch - |
| 1 VCR | SHIFT + 1 Shift + 1 |
| 2 VCR | SHIFT + 2 Shift + 2 |
| 3 VCR | SHIFT + 3 Shift + 3 |
| 4 VCR | SHIFT + 4 Shift + 4 |
| 5 VCR | SHIFT + 5 Shift + 5 |
| 6 VCR | SHIFT + 6 Shift + 6 |
| 7 VCR | SHIFT + 7 Shift + 7 |
| 8 VCR | SHIFT + 8 Shift + 8 |
| 9 VCR | SHIFT + 9 Shift + 9 |
| 0 VCR | SHIFT + 0 Shift + 0 |
| * TXT Text VCR | REPEAT TEXT Text |
| # HELP #Help VCR | FAV PRE-CH Pre Ch |