Originale		Sostituto	
ON/STANDBY	On/Standby		Power
SLEEP	Sleep	PROG SLEEP	Sleep
CBL/SAT	CBL/SAT	1	1
DVD	DVD	2	2
Blu-ray	Blu-ray	3	3
GAME	Game	4	4
AUX	AUX	TIMER AV	AV
MEDIA PLAYER	Media Player	5	5
TV AUDIO	TV Audio	SEARCH TV/R	TV/R
CD	CD	6	6
TUNER	Tuner	7	7
iPod /USB	iPod/USB	8	8
PHONO	Phono	9	9
M-XPort	M-XPort	-/-- GUIDE	Guide
NETWORK	Network	0	0
INTERNET RADIO	Internet Radio	FAV PRE-CH	Pre Ch
CH / PAGE	CH+	+ CH	Ch +

Originale		Sostituto	
CH / PAGE	CH-	CH –	Ch -
MUTE	Mute	MUTE	Mute
VOLUME	Vol+	+ VOL	Vol +
VOLUME	Vol-	VOL –	Vol -
INFO	Info	DISPLAY INFO	Info
OPTION	Option	SETTINGS OPT	Options
	Up		Up
	Down		Down
	Right		Right
	Left		Left
ENTER	OK	OK	Ok
BACK	Back	RETURN BACK	Back
SETUP	Setup	TOP MENU MENU	Menu
TUNE +	>>I/Tune+		>>I
TUNE –	I<<</Tune-		I<<
	Play	PLAY MODE	Play
	Pause		Pause

Originale		Sostituto	
1	Favorite Station 1	DISC NAV LIST	List
2	Favorite Station 2	SOUND DUAL	Dual
3	Favorite Station 3	AD SUBT	Subt
MOVIE	Red/Movie	A	Red
MUSIC	Green/Music	B	Green
GAME	Blue/Game	D	Blue
PURE	Yellow/Pure	C	Yellow

Originale	Sostituto

Originale		Sostituto	
ON/STANDBY	On/Standby		Power
SLEEP	Sleep	PROG SLEEP	Sleep
CBL/SAT	CBL/SAT	1	1
DVD	DVD	2	2
Blu-ray	Blu-ray	3	3
GAME	Game	4	4
AUX	AUX	TIMER AV	AV
MEDIA PLAYER	Media Player	5	5
TV AUDIO	TV Audio	SEARCH TV/R	TV/R
CD	CD	6	6
TUNER	Tuner	7	7
iPod /USB	iPod/USB	8	8
PHONO	Phono	9	9
M-XPort	M-XPort	-/-- GUIDE	Guide
NETWORK	Network	0	0
INTERNET RADIO	Internet Radio	FAV PRE-CH	Pre Ch
CH / PAGE	CH+	+ CH	Ch +

Originale		Sostituto	
CH / PAGE	CH-	CH –	Ch -
MUTE	Mute	MUTE	Mute
VOLUME	Vol+	+ VOL	Vol +
VOLUME	Vol-	VOL –	Vol -
OPTION	Option	SETTINGS OPT	Options
	Up		Up
	Down		Down
	Right		Right
	Left		Left
ENTER	Enter	OK	Ok
BACK	Back	RETURN BACK	Back
TUNE +	>>I/Tune+		>>I
TUNE –	I<<</Tune-		I<<
	Play	PLAY MODE	Play
	Pause		Pause
1	Favorite Station 1	DISC NAV LIST	List
2	Favorite Station 2	SOUND DUAL	Dual

Originale	Sostituto	Originale	Sostituto
3 Favorite Station 3	PICTURE FORMAT Format		