Originale		Sostituto	
AVR/AVC ON	AVR/AVC On		Power
OFF	AVR/AVC Off	SHIFT +	Shift + Power
POW TV	Power Tv	SEARCH TV/R	TV/R
POWER VCR	Power VCR	HOME SMART	Smart
DVD/VDP	Power DVD/VDP	APP MEDIA	Media
	Yellow Nothing 1	1	1
CD	CD	2	2
DVD/VDP	DVD/VDP	3	3
VCR	VCR	4	4
	Yellow Nothing 2	5	5
TV/DBS	TV/DBS	6	6
MD/ TAPE MON	MD/Tape Mon	7	7
TUNER	Tuner	8	8
SHIFT	Shift	9	9
VIDEO SELECT	Video Select	0	0
INPUT MODE	Input Mode	-/-- GUIDE	Guide
SURROUND MODE	Surround Mode	FAV PRE-CH	Pre Ch

Originale		Sostituto	
	<< Deck-VCR	SHIFT +	Shift + <<
	< Deck-VCR	SHIFT + PLAY MODE	Shift + Play
	Deck-VCR >	SHIFT +	Shift + Pause
	Deck-VCR >>	SHIFT +	Shift + >>
	Stop Deck-VCR	SHIFT +	Shift + Stop
CHANNEL +	CH+	+ CH	Ch +
CHANNEL −	CH-	CH −	Ch -
DISC SKIP+	Disc Skip+	D	Blue
	Play CD/MD/CDR-DVD/	PLAY MODE	Play
	Stop CD/MD/CDR-DVD/		Stop
	Pause CD/MD/CDR-DVD/		Pause
	CD/MD/CDR-DVD/ VDP >>I		>>I
	I<< CD/MD/CDR-DVD/		I<<
	CD/MD/CDR-DVD/ VDP >>		>>
	<< CD/MD/CDR-DVD/		<<
SYSTEM SET UP	System/Setup	TOP MENU MENU	Menu
SURROUND MENU	Surround/Menu	E-MANUAL D.MENU	D. Menu

Originale	Sostituto	Originale	Sostituto
T.TONE RETURN T.Tone/Return	RETURN BACK Back		
STATUS DISPLAY Status/Display	DISPLAY INFO Info		
Up	Up		
Down	Down		
Right	Right		
Left	Left		
CH.SELECT SELECT CH.Select/Select	OK Ok		
MASTER VOL. Master Volume	VOL + Vol +		
MASTER VOL. Master Volum	VOL − Vol -		
MUTING Muting	MUTE Mute		
VOLUME Tv Vol+	SHIFT + VOL + Shift + Vol +		
TV VOLU Tv Vol-	SHIFT + VOL − Shift + Vol -		
CHANNEL TV Tv CH+	SHIFT + CH + Shift + Ch +		
CHAN Tv CH-	SHIFT + CH − Shift + Ch -		

Originale	Sostituto	Originale	Sostituto
AVR/AVC ON — AVR/AVC On	Power		
OFF — AVR/AVC Off	SHIFT + Power		
Play CD/MD/CDR-DVD/	PLAY MODE — Play		
Pause CD/MD/CDR-DVD/	Pause		
Stop CD/MD/CDR-DVD/	Stop		
CD/MD/CDR-DVD/ VDP >>I	>>I		
I<< CD/MD/CDR-DVD/	I<<		
CD/MD/CDR-DVD/ VDP >>	>>		
<< CD/MD/CDR-DVD/	<<		

Originale	Sostituto
AVR/AVC ON — AVR/AVC On	Power
OFF — AVR/AVC Off	SHIFT + Power — Shift + Power
+ CHANNEL — CH+	+ CH — Ch +
CHANNEL − — CH-	CH − — Ch -
Deck-VCR >>	>>
<< Deck-VCR	<<
Deck-VCR >	SHIFT + Pause — Shift + Pause
Stop Deck-VCR	SHIFT + Stop — Shift + Stop
TITLE — Title CD/MD/CDR-DVD/	CLEAR EXIT — Exit
DISC SKIP+ — Disc Skip+ CD/MD/CDR-DVD/	D — Blue
Play CD/MD/CDR-DVD/	PLAY MODE — Play
Pause CD/MD/CDR-DVD/	Pause
Stop CD/MD/CDR-DVD/	Stop
CD/MD/CDR-DVD/ VDP >>I	>>I
I<< CD/MD/CDR-DVD/	I<<
SYSTEM SET UP — System/Setup	TOP MENU MENU — Menu
SURROUND MENU — Surround/Menu	E-MANUAL D.MENU — D. Menu

Originale	Sostituto
T.TONE RETURN — T.Tone/Return	RETURN BACK — Back
STATUS DISPLAY — Status/Display	DISPLAY INFO — Info
Up	Up
Down	Down
Right	Right
Left	Left
CH.SELECT SELECT — CH.Select/Select	OK — Ok