Mandis shop

RM-D335

Originale		Sostituto	
CONTINUE	Continue	APP MEDIA	Media
SHUFFLE	Shuffle	SEARCH TV/R	TV/R
PROGRAM	Program	PROG SLEEP	Sleep
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
10	10	0	0
>10	>10	-/-- GUIDE	Guide
CLEAR	Clear	CLEAR EXIT	Exit
DISC 1	Disc 1	A	Red
DISC 2	Disc 2	B	Green

Originale		Sostituto	
DISC 3	Disc 3	C	Yellow
DISC 4	Disc 4	D	Blue
DISC 5	Disc 5	HOME SMART	Smart
DISC SKIP	Disc Skip	RETURN BACK	Back
▶	Play	PLAY MODE ▶	Play
❚❚	Pause	❚❚	Pause
■	Stop	■	Stop
AMS ⏮	I<< AMS	⏮	I<<
AMS ⏭	AMS >>I	⏭	>>I
◀◀	<<	«	<<
▶▶	>>	»	>>
M. SCAN	M.Scan	FAV PRE-CH	Pre Ch
FADER	Fader	MUTE	Mute

https://tutti-i-telecomandi.it/it/Sony/1057417-30866-telecomando-di-sostituzione-per-Sony-RM-D335.html