Mandis shop

Philips 996580000582

Originale		Sostituto	
	Power		Power
AUX	AUX	TIMER AV	AV
AUDIO IN	Audio In	SOUND DUAL	Dual
COAX	Coax	APP MEDIA	Media
OPTICAL	Optical	SETTINGS OPT	Options
USB	USB	HOME SMART	Smart
	Play	PLAY MODE	Play
	Pause		Pause
	I<		I<<
	>I		>>I
BASS +	Bass+	CH +	Ch +
BASS –	Bass-	CH –	Ch -
VOLUME +	Vol+	VOL +	Vol +
VOLUME –	Vol-	VOL –	Vol -
	Mute	MUTE	Mute
TREBLE +	Treble+		Up
TREBLE –	Treble-		Down

Originale		Sostituto	
SURR OFF	Surr. Off		Right
SURR ON	Surr. On		Left

https://tutti-i-telecomandi.it/it/Philips/1058142-79363-telecomando-di-sostituzione-per-Philips-996580000582.html