Originale	Sostituto
Power	Power
Mute	Mute
Display	Info
P.Mode	Shift + Format
S.Mode	Shift + Dual
Subtitle	Subt
Sleep	Sleep
P.Size	Format
Nicam/A2	Options
Auto	D. Menu
1	1
2	2
3	3
4	4
5	5
6	6
7	7

Originale	Sostituto
8	8
9	9
0	0
-/--	Guide
Recall	Back
I<< USB	I<<
>>I USB	>>I
<< USB	<<
>> USB	>>
Media USB	Media
Play USB	Play
Pause USB	Pause
Stop USB	Stop
Rec/PVR USB	Rec
Vol+ USB	Shift + Right
Vol- USB	Shift + Left
FAV	Pre Ch

Originale	Sostituto
FAV+	SHIFT + CH + (Shift + Ch +)
FAV-	SHIFT + CH − (Shift + Ch -)
Menu	TOP MENU MENU (Menu)
Exit	CLEAR EXIT (Exit)
TV/AV	TIMER AV (AV)
EPG	SHIFT + GUIDE (Shift + Guide)
CH+	CH + (Ch +)
CH-	CH − (Ch -)
Up	▲ (Up)
Down	▼ (Down)
Right	▶ (Right)
Left	◀ (Left)
Enter	OK (Ok)
Vol+	VOL + (Vol +)
Vol-	VOL − (Vol -)
Text	REPEAT TEXT (Text)
Tv/Radio	SEARCH TV/R (TV/R)

Originale	Sostituto
Hold	ZOOM ⏏ (Eject)
Audio	SOUND DUAL (Dual)
Index	DISC NAV LIST (List)
Subpage	SHIFT + AD SUBT (Shift + Subt)
Reveal	HOME SMART (Smart)
Size	ECO 3D (3D)
Red	A (Red)
Green	B (Green)
Yellow	C (Yellow)
Cyan	D (Blue)