Originale		Sostituto	
	Power		Power
SOURCE	Source	TIMER AV	AV
HDMI	HDMI	E-MANUAL D.MENU	D. Menu
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
TTX/MIX	TTX/MIX	REPEAT TEXT	Text
PRE-CH	PRE-CH	FAV PRE-CH	Pre Ch
+	Vol+	+ VOL	Vol +
−	Vol-	VOL −	Vol -

Originale		Sostituto	
MUTE	Mute	MUTE	Mute
P	P+	+ CH	Ch +
P	P-	CH −	Ch -
CH LIST	CH List	DISC NAV LIST	List
MENU	Menu	TOP MENU MENU	Menu
GUIDE	Guide	-/-- GUIDE	Guide
	Smart Hub	HOME SMART	Smart
TOOLS	Tools	SETTINGS OPT	Options
INFO	Info	DISPLAY INFO	Info
RETURN BACK	BacK/Return	RETURN BACK	Back
EXIT	Exit	CLEAR EXIT	Exit
▲	Up	▲	Up
▼	Down	▼	Down
▶	Right	▶	Right
◀	Left	◀	Left
OK	OK	OK	Ok
A	Red	A	Red

Originale		Sostituto	
B	Green	B	Green
C	Yellow	C	Yellow
D	Blue	D	Blue
Family Story	Family Story	APP MEDIA	Media
SEARCH	Search	SEARCH TV/R	TV/R
P.SIZE	P.Size	PICTURE FORMAT	Format
SUPPORT	Support	ZOOM	Eject
D	D	ECO 3D	3D
AD/SUBT.	AD/Subt.	AD SUBT	Subt
<<	<<	<<	<<
I<<	I<<	I<<	I<<
Pause	Pause	Pause	Pause
>>	>>	>>	>>
>>I	>>I	>>I	>>I
Rec	Rec	REC MODE	Rec
Play	Play	PLAY MODE	Play
Stop	Stop	Stop	Stop

Originale	Sostituto