Originale		Sostituto	
ON	On		Power
STANDBY	Standby	SHIFT +	Shift + Power
1	ID 1	A	Red
2	ID 2	B	Green
3	ID 3	C	Yellow
4	ID 4	D	Blue
COM PUTER 1	Computer 1	1	1
COM PUTER 2	Computer 2	2	2
COM PUTER 3	Computer 3	3	3
LAN	LAN	4	4
USB TYPE A	USB Type A	5	5
USB TYPE B	USB Type B	6	6
COM PONENT	Component	7	7
S-VIDEO	S.Video	8	8
VIDEO	Video	9	9
HDMI 1	HDMI 1	-/-- GUIDE	Guide
HDMI 2	HDMI 2	0	0

Originale		Sostituto	
DIGITAL	Digital	FAV PRE-CH	Pre Ch
PAGE UP	Page Up	+ CH	Ch +
PAGE DOWN	Page Down	CH –	Ch -
ON MAGNIFY	Magnify On	HOME SMART	Smart
MAGNIFY OFF	Magnify Off	APP MEDIA	Media
+ VOL	Vol+	+ VOL	Vol +
VOL –	Vol-	VOL –	Vol -
AV MUTE	AV Mute	MUTE	Mute
FREEZE	Freeze	II	Pause
F5	F5	REPEAT TEXT	Text
RESET	Reset	TIMER AV	AV
MENU	Menu	TOP MENU MENU	Menu
▲	Up	▲	Up
▼	Down	▼	Down
▶	Right	▶	Right
◀	Left	◀	Left
ENTER	Enter	OK	Ok

Originale		Sostituto	
ESC	ESC	CLEAR EXIT	Exit
PbyP	PbyP	PICTURE FORMAT	Format
ASPECT	Aspect	ECO 3D	3D
AUTO	Auto	SEARCH TV/R	TV/R
1	My Button 1	SHIFT + 1	Shift + 1
MY B 2	My Button 2	SHIFT + 2	Shift + 2
UTTON 3	My Button 3	SHIFT + 3	Shift + 3
4	My Button 4	SHIFT + 4	Shift + 4
POSITION	Position	SETTINGS OPT	Options
LENS SHIFT	Lens Shift	DISPLAY INFO	Info
KEYSTONE	Keystone	SOUND DUAL	Dual
LENS MEMORY	Lens Memory	RETURN BACK	Back
+ FOCUS	Focus +	>>	>>
FOCUS –	Focus -	<<	<<
+ ZOOM	Zoom +	>>I	>>I
ZOOM –	Zoom -	I<<	I<<

Originale	Sostituto

Originale		Sostituto	
ON	On		Power
STANDBY	Standby	SHIFT +	Shift + Power
1	ID 1	A	Red
2	ID 2	B	Green
3	ID 3	C	Yellow
4	ID 4	D	Blue
COM PUTER 1	Computer 1	1	1
COM PUTER 2	Computer 2	2	2
COM PUTER 3	Computer 3	3	3
LAN	LAN	4	4
USB TYPE A	USB Type A	5	5
USB TYPE B	USB Type B	6	6
COM PONENT	Component	7	7
S-VIDEO	S.Video	8	8
VIDEO	Video	9	9
HDMI 1	HDMI 1	GUIDE	Guide
HDMI 2	HDMI 2	0	0

Originale		Sostituto	
DIGITAL	Digital	FAV PRE-CH	Pre Ch
PAGE UP	Page Up	+ CH	Ch +
PAGE DOWN	Page Down	CH –	Ch -
ON MAGNIFY	Magnify On	HOME SMART	Smart
MAGNIFY OFF	Magnify Off	APP MEDIA	Media
+ VOL	Vol+	+ VOL	Vol +
VOL –	Vol-	VOL –	Vol -
AV MUTE	AV Mute	MUTE	Mute
FREEZE	Freeze	II	Pause
F5	F5	REPEAT TEXT	Text
RESET	Reset	TIMER AV	AV
MENU	Menu	TOP MENU MENU	Menu
▲	Up	▲	Up
▼	Down	▼	Down
▶	Right	▶	Right
◀	Left	◀	Left
ENTER	Enter	OK	Ok

Originale		Sostituto	
ESC	ESC	CLEAR EXIT	Exit
PbyP	PbyP	PICTURE FORMAT	Format
ASPECT	Aspect	ECO 3D	3D
AUTO	Auto	SEARCH TV/R	TV/R
1	My Button 1	SHIFT + 1	Shift + 1
MY B 2	My Button 2	SHIFT + 2	Shift + 2
UTTON 3	My Button 3	SHIFT + 3	Shift + 3
4	My Button 4	SHIFT + 4	Shift + 4
POSITION	Position	SETTINGS OPT	Options
LENS SHIFT	Lens Shift	DISPLAY INFO	Info
KEYSTONE	Keystone	SOUND DUAL	Dual
LENS MEMORY	Lens Memory	RETURN BACK	Back
+ FOCUS	Focus +	≫	>>
FOCUS –	Focus -	≪	<<
+ ZOOM	Zoom +	≫I	>>I
ZOOM –	Zoom -	I≪	I<<

Originale	Sostituto

Originale		Sostituto	
ON	On		Power
STANDBY	Standby	SHIFT +	Shift + Power
1	ID 1	A	Red
2	ID 2	B	Green
3	ID 3	C	Yellow
4	ID 4	D	Blue
COM PUTER 1	Computer 1	1	1
COM PUTER 2	Computer 2	2	2
COM PUTER 3	Computer 3	3	3
LAN	LAN	4	4
USB TYPE A	USB Type A	5	5
USB TYPE B	USB Type B	6	6
COM PONENT	Component	7	7
S-VIDEO	S.Video	8	8
VIDEO	Video	9	9
HDMI 1	HDMI 1	-/-- GUIDE	Guide
HDMI 2	HDMI 2	0	0

Originale		Sostituto	
DIGITAL	Digital	FAV PRE-CH	Pre Ch
PAGE UP	Page Up	+ CH	Ch +
PAGE DOWN	Page Down	CH –	Ch -
ON MAGNIFY	Magnify On	HOME SMART	Smart
MAGNIFY OFF	Magnify Off	APP MEDIA	Media
+ VOL	Vol+	+ VOL	Vol +
VOL –	Vol-	VOL –	Vol -
AV MUTE	AV Mute	MUTE	Mute
FREEZE	Freeze	II	Pause
F5	F5	REPEAT TEXT	Text
RESET	Reset	TIMER AV	AV
MENU	Menu	TOP MENU MENU	Menu
▲	Up	▲	Up
▼	Down	▼	Down
▶	Right	▶	Right
◀	Left	◀	Left
ENTER	Enter	OK	Ok

Originale		Sostituto	
ESC	ESC	CLEAR EXIT	Exit
PbyP	PbyP	PICTURE FORMAT	Format
ASPECT	Aspect	ECO 3D	3D
AUTO	Auto	SEARCH TV/R	TV/R
1	My Button 1	SHIFT + 1	Shift + 1
MY B 2	My Button 2	SHIFT + 2	Shift + 2
UTTON 3	My Button 3	SHIFT + 3	Shift + 3
4	My Button 4	SHIFT + 4	Shift + 4
POSITION	Position	SETTINGS OPT	Options
LENS SHIFT	Lens Shift	DISPLAY INFO	Info
KEYSTONE	Keystone	SOUND DUAL	Dual
LENS MEMORY	Lens Memory	RETURN BACK	Back
+ FOCUS	Focus +	>>	>>
FOCUS –	Focus -	<<	<<
+ ZOOM	Zoom +	>>I	>>I
ZOOM –	Zoom -	I<<	I<<

Originale	Sostituto

Originale		Sostituto	
ON	On		Power
STANDBY	Standby	SHIFT +	Shift + Power
1	ID 1	A	Red
2	ID 2	B	Green
3	ID 3	C	Yellow
4	ID 4	D	Blue
COM PUTER 1	Computer 1	1	1
COM PUTER 2	Computer 2	2	2
COM PUTER 3	Computer 3	3	3
LAN	LAN	4	4
USB TYPE A	USB Type A	5	5
USB TYPE B	USB Type B	6	6
COM PONENT	Component	7	7
S-VIDEO	S.Video	8	8
VIDEO	Video	9	9
HDMI 1	HDMI 1	GUIDE	Guide
HDMI 2	HDMI 2	0	0

Originale		Sostituto	
DIGITAL	Digital	FAV PRE-CH	Pre Ch
PAGE UP	Page Up	+ CH	Ch +
PAGE DOWN	Page Down	CH –	Ch -
ON MAGNIFY	Magnify On	HOME SMART	Smart
MAGNIFY OFF	Magnify Off	APP MEDIA	Media
+ VOL	Vol+	+ VOL	Vol +
VOL –	Vol-	VOL –	Vol -
AV MUTE	AV Mute	MUTE	Mute
FREEZE	Freeze	II	Pause
F5	F5	REPEAT TEXT	Text
RESET	Reset	TIMER AV	AV
MENU	Menu	TOP MENU MENU	Menu
▲	Up	▲	Up
▼	Down	▼	Down
▶	Right	▶	Right
◀	Left	◀	Left
ENTER	Enter	OK	Ok

Originale		Sostituto	
ESC	ESC	CLEAR EXIT	Exit
PbyP	PbyP	PICTURE FORMAT	Format
ASPECT	Aspect	ECO 3D	3D
AUTO	Auto	SEARCH TV/R	TV/R
1	My Button 1	SHIFT + 1	Shift + 1
MY B 2	My Button 2	SHIFT + 2	Shift + 2
UTTON 3	My Button 3	SHIFT + 3	Shift + 3
4	My Button 4	SHIFT + 4	Shift + 4
POSITION	Position	SETTINGS OPT	Options
LENS SHIFT	Lens Shift	DISPLAY INFO	Info
KEYSTONE	Keystone	SOUND DUAL	Dual
LENS MEMORY	Lens Memory	RETURN BACK	Back
+ FOCUS	Focus +	≫	>>
FOCUS –	Focus -	≪	<<
+ ZOOM	Zoom +	≫I	>>I
ZOOM –	Zoom -	I≪	I<<

Originale	Sostituto