Originale		Sostituto	
POWER	Power		Power
INFO	Info	ANGLE INFO	Info / Angle
	Mute	DIMMER MUTE	Mute / Dimmer
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
SOURCE	Source	RDS AV INPUT	AV / Input / RDS
0	0	HDMI - SAT 0	0
AUDIO	Audio I/II	LANG I/II AUDIO	Audio / Lang I/II
MENU	Menu	HOME MENU	Menu / Home
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear

Originale		Sostituto	
	Up		Up
	Left		Left
ENTER	Enter	OK	OK
	Right		Right
	Down		Down
CH+	CH +	CH PAGE +	CH+ / Page+
INDEX	Index	MEDIA DISPLAY	Display / Media
VOL+	Vol +	VOL +	Vol +
CH-	CH -	CH PAGE -	CH- / Page-
LIST	List	LIST SMART	Smart / List
VOL-	Vol -	VOL -	Vol -
	Fav	PC FAV MARKER	Fav / Marker / PC
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
EPG	EPG	-/-- GUIDE EPG	Guide / EPG / -/--
	Recall	RETURN BACK	Back / Return
	Red / <<	TUNE-	<< / Tune-
	Red / <<	NETFLIX SEARCH	Red / Netflix / Search

Originale	Sostituto	Originale	Sostituto
Green / >>	>> / Tune+		
Green / >>	Green / APP / Repeat		
Yellow / I<<	I<< / Preset-		
Yellow / I<<	Yellow / YouTube / Repeat		
Blue / >>I	>>I / Preset+		
Blue / >>I	Blue / Prime Video / Random		
Text / Play/Paus	Text / Goto		
Text / Play/Paus	Play / Slow		
Text / Play/Paus	Pause / Step / Freeze		
Stop / Still	Stop / Hold		
Radio	TV/Radio /		
Size / Aspect	Picture / Format		
Size / Aspect	Zoom / Size		
[≡x]	Eject / Surround		
Subtitle / [≡o]	Subtitle / EQ		
DMP	D.Menu / Top		
Rec	Rec / Rec Mode		

Originale		Sostituto	
POWER	Power		Power
INFO	Info	ANGLE INFO	Info / Angle
	Mute	DIMMER MUTE	Mute / Dimmer
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
SOURCE	Source	RDS AV INPUT	AV / Input / RDS
0	0	HDMI - SAT 0	0
AUDIO	O) / I - II / Audi	LANG I/II AUDIO	Audio / Lang I/II
MENU	Menu	HOME MENU	Menu / Home
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear

Originale		Sostituto	
	Up		Up
	Left		Left
ENTER	Enter	OK	OK
	Right		Right
	Down		Down
CH+	CH+	CH PAGE +	CH+ / Page+
INDEX	Index	MEDIA DISPLAY	Display / Media
VOL+	Vol +	VOL +	Vol +
CH-	CH-	CH PAGE -	CH- / Page-
LIST	List	LIST SMART	Smart / List
VOL-	Vol -	VOL -	Vol -
♥	♥	PC FAV MARKER	Fav / Marker / PC
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
EPG	EPG	-/-- GUIDE EPG	Guide / EPG / -/--
	Recall	RETURN BACK	Back / Return
	Red	NETFLIX SEARCH	Red / Netflix / Search
	<<	TUNE-	<< / Tune-

Originale	Sostituto	Originale	Sostituto
Green	Green / APP / Repeat		
>>	>> / Tune+		
Yellow	Yellow / YouTube / Repeat		
I <<	I << / Preset-		
Blue	Blue / Prime Video / Random		
>>I	>>I / Preset+		
[≡]	Text / Goto		
Play	Play / Slow		
Pause	Pause / Step / Freeze		
[≡+]	Shift + Stop /		
Stop/Still	Stop / Hold		
Radio	TV/Radio /		
[≡♦] / [++]	Zoom / Size		
[≡x]	Eject / Surround		
[≡o] / Subtitle	Subtitle / EQ		
DMP	D.Menu / Top		
Rec	Rec / Rec Mode		