Originale		Sostituto	
RECEIVER	Power Receiver		Power
TUNER	Tuner	SHIFT + TUNER 6	Shift + 6
CD/DVD	CD/DVD	SHIFT + CD-STB 3	Shift + 3
MD/TAPE	MD/Tape	SHIFT + TAPE 5	Shift + 5
VIDEO 1	Video 1	SHIFT + TV 1	Shift + 1
VIDEO 2	Video 2	SHIFT + VIDEO 4	Shift + 4
DVD/6CH	DVD / 6CH	SHIFT + DVD 2	Shift + 2
AUX	AUX	SHIFT + AUX-HDD 7	Shift + 7
DVD	Power DVD	SHIFT +	Shift + Power
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
7	7	AUX-HDD 7	7

Originale		Sostituto	
8	8	USB 8	8
9	9	BLUETOOTH 9	9
TONE	Tone	GOTO TEXT	Text / Goto
+10	+10	-/-- GUIDE EPG	Guide / EPG / -/--
0	0	HDMI-SAT 0	0
DIMMER	Dimmer	SHIFT + DIMMER MUTE	Shift + Mute / Dimmer
SOUND	Sound	TITLE SOUND	Sound / Title
LISTEN MODE	Listen Mode	LIST SMART	Smart / List
ACTIVE EQ	Active EQ	MEDIA DISPLAY	Display / Media
MULTI CONTROL	Multicontrol Dow	CH PAGE -	CH- / Page-
CONTROL	Multicontrol U	CH PAGE +	CH+ / Page+
TOP MENU	Top Menu	TOP MENU D.MENU	D.Menu / Top
	Up		Up
MENU	Menu	HOME MENU	Menu / Home
VOLUME	Volume +	VOL +	Vol +
	Left		Left
ENTER	Enter	OK	OK

Originale		Sostituto	
	Right		Right
	Down		Down
	Volume -	VOL	Vol -
RETURN	Return	RETURN BACK	Back / Return
ON SCREEN	On Screen	RDS AV INPUT	AV / Input / RDS
	Pause	STEP-FREEZE	Pause / Step / Freeze
BAND	Play/Pause / Ban	SLOW	Play / Slow
AUTO/MONO	Stop / Auto/Mono	HOLD	Stop / Hold
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
P.CAL	I<< / P.Call	PRESET-	I<< / Preset-
P.CALL	>>I / P.Call	PRESET+	>>I / Preset+
TUNIN	<< / Tuning -	TUNE-	<< / Tune-
TUNING	>> / Tuning +	TUNE+	>> / Tune+
BASS BOOST	Bass Boost	FORMAT PICTURE	Picture / Format
LOUDNESS	Loudness	SIZE ZOOM	Zoom / Size
RDS DISP. DISC SEL.	RDS Disp / Disc Sel.	SURROUND	Eject / Surround
PTY DISC SKIP	PTY / Disc Ski	PROGRAM TV/ RADIO	TV/Radio / Program

Originale		Sostituto	
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ
ANGLE	Angle	ANGLE INFO	Info / Angle
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat

Originale		Sostituto	
RECEIVER	Power Receiver		Power
TUNER	Tuner	SHIFT + TUNER 6	Shift + 6
CD/DVD	CD / DVD	SHIFT + CD-STB 3	Shift + 3
MD/TAPE	MD/Tape	SHIFT + TAPE 5	Shift + 5
VIDEO 1	Video 1	SHIFT + TV 1	Shift + 1
VIDEO 2	Video 2	SHIFT + VIDEO 4	Shift + 4
DVD/6CH	DVD / 6CH	SHIFT + DVD 2	Shift + 2
AUX	AUX	SHIFT + AUX-HDD 7	Shift + 7
DVD	Power DVD	SHIFT +	Shift + Power
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
7	7	AUX-HDD 7	7

Originale		Sostituto	
8	8	USB 8	8
9	9	BLUETOOTH 9	9
TONE	Tone	GOTO TEXT	Text / Goto
+10	+10	-/-- GUIDE EPG	Guide / EPG / -/--
0	0	HDMI-SAT 0	0
DIMMER	Dimmer	SHIFT + DIMMER MUTE	Shift + Mute / Dimmer
SOUND	Sound	TITLE SOUND	Sound / Title
LISTEN MODE	Listen Mode	LIST SMART	Smart / List
ACTIVE EQ	Active EQ	MEDIA DISPLAY	Display / Media
MULTI CONTROL	Multicontrol Down	CH PAGE -	CH- / Page-
CONTROL	Multicontrol Up	CH PAGE +	CH+ / Page+
TOP MENU	Top Menu	TOP MENU D.MENU	D.Menu / Top
	Up		Up
MENU	Menu	HOME MENU	Menu / Home
VOLUME	Volume +	VOL +	Vol +
	Left		Left
ENTER	Enter	OK	OK

Originale		Sostituto	
	Right		Right
	Down		Down
	Volume -	VOL	Vol -
RETURN	Return	RETURN BACK	Back / Return
ON SCREEN	On Screen	RDS AV INPUT	AV / Input / RDS
	Pause	STEP-FREEZE	Pause / Step / Freeze
BAND	Play/Pause / Ban	SLOW	Play / Slow
AUTO/MONO	Stop / Auto/Mono	HOLD	Stop / Hold
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
P.CAL	I<< / P.Call	PRESET-	I<< / Preset-
P.CALL	>>I / P.Call	PRESET+	>>I / Preset+
TUNIN	<< / Tuning -	TUNE-	<< / Tune-
TUNING	>> / Tuning +	TUNE+	>> / Tune+
BASS BOOST	Bass Boost	FORMAT PICTURE	Picture / Format
LOUDNESS	Loudness	SIZE ZOOM	Zoom / Size
RDS DISP. DISC SEL.	RDS Disp / Disc Sel.	SURROUND	Eject / Surround
PTY DISC SKIP	PTY / Disc Ski	PROGRAM TV/ RADIO	TV/Radio / Program

Originale		Sostituto	
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ
ANGLE	Angle	ANGLE INFO	Info / Angle
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat