Mandis shop

REMCON278

Originale		Sostituto	
	Power		Power
	TV / Radio	SEARCH TV/R	TV/R
	Mute	MUTE	Mute
	i	DISPLAY INFO	Info
	ALT	RETURN BACK	Back
	M/A	HOME SMART	Smart
	Teletext	REPEAT TEXT	Text
	Exit	CLEAR EXIT	Exit
	Menu	TOP MENU MENU	Menu
	FAV	FAV PRE-CH	Pre Ch
	P/L	APP MEDIA	Media
	Up		Up
	Left		Left
	OK	OK	Ok
	Right		Right
	Down		Down
	Vol +	+ VOL	Vol +

Originale		Sostituto	
	Vol -	VOL –	Vol -
	PG+	+ CH	Ch +
	PG-	CH –	Ch -
	1	1	1
	2	2	2
	3	3	3
	4	4	4
	5	5	5
	6	6	6
	7	7	7
	8	8	8
	9	9	9
	0	0	0

https://tutti-i-telecomandi.it/it/1060334-48281-telecomando-di-sostituzione-per-REMCON278.html