Originale		Sostituto	
DVD Power	DVD Power		Power
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
Open / Close	Open / Close	CLEAR EXIT	Exit
SET UP	Setup	SETTINGS OPT	Options
ZOOM	Zoom	ZOOM	Eject
3D SOUND	3D Sound	ECO 3D	3D
BOOKMARK	Bookmark	FAV PRE-CH	Pre Ch
VOLUME CON.	Volume Con.	-/-- GUIDE	Guide

Originale		Sostituto	
<<	<<	<<	<<
>>	>>	>>	>>
Stop	Stop	Stop	Stop
Play / Pause	Play / Pause	PLAY MODE ▶	Play
Play / Pause	Play / Pause	II	Pause
I<<	I<<	I<<	I<<
>>I	>>I	>>I	>>I
Return	Return	RETURN BACK	Back
Step	Step	SHIFT + II	Shift + Pause
Clear	Clear	SHIFT + CLEAR EXIT	Shift + Exit
Top Menu	Top Menu	SHIFT + TOP MENU MENU	Shift + Menu
Top Menu	Top Menu	E-MANUAL D.MENU	D. Menu
DISPLAY	Display	DISPLAY INFO	Info
MENU	Menu	TOP MENU MENU	Menu
	Up	▲	Up
	Left	◀	Left
ENTER	Enter	OK	Ok

Originale	Sostituto	Originale	Sostituto
Right	Right		
Down	Down		
Audio	SOUND DUAL		
Sub Title	AD SUBT		
Angle	PICTURE FORMAT		
Repeat	REPEAT TEXT		
Repeat A-B	SHIFT + REPEAT TEXT Shift + Text		